



GEO

GEO3.1

USER MANUAL

WARNING

ADHERE STRICTLY TO THESE AND ALL OTHER SAFETY INSTRUCTIONS AND GUIDELINES!

- Please read and understand all instruction manuals before use.
- The Eclipse GEO3.1 is not a toy. **PAINTBALL SAFETY RULES MUST BE FOLLOWED AT ALL TIMES.**
- Careless or improper use, including failure to follow instructions and warnings within this User Manual and attached to the GEO3.1 could cause death or serious injury.
- Do not remove or deface any warnings attached to the GEO3.1.
- Paintball industry standard eye/face/ear and head protection designed specifically to stop paintballs and meeting ASTM standard F1776 (USA) or CE standard (Europe) must be worn by the user and any person within range. Proper protection must be worn during assembly, cleaning and maintenance.
- Hearing protection should be worn.
- Never shoot at a person who is not wearing proper protection.
- Never look directly into the barrel of the marker. Accidental discharge into the eyes may cause permanent injury or death. Never look into the barrel or breech area of the GEO3.1 whilst the marker is switched on and able to fire.
- Keep the GEO3.1 switched off until ready to shoot.
- Treat every marker as if it is loaded and ready to fire.
- The electronic on/off is the markers safety, always switch off the marker when not in use.
- Always fit a barrel-blocking device to the GEO3.1 when not in use.
- Always remove all paintballs from the GEO3.1 when not in use on the field of play.
- Never point the GEO3.1 at anything you do not intend to shoot.
- Do not shoot at persons within close range.
- Do not field strip or remove any parts while the marker is pressurised.
- Do not pressurise the GEO3.1 without all the components of the marker correctly installed, as high-pressure gas may be emitted.
- Do not fire the GEO3.1 without the bolt correctly installed.
- Never put your finger or any foreign objects into the paintball feed tube of the GEO3.1.
- Never allow pressurised gas to come into contact with any part of your body.
- Always remove the first stage regulator and relieve all residual gas pressure from the GEO3.1 before disassembly.
- Always remove the first stage regulator and relieve all residual gas pressure from the GEO3.1 for transport and storage.
- Always follow guidelines given with your first stage regulator for safe transportation and storage.
- Always store the GEO3.1 in a secure place.
- Persons under 18 years of age must have adult supervision when using or handling the GEO3.1.
- Observe all local and national laws, regulations and guidelines.

WARNING

ADHERE STRICTLY TO THESE AND ALL OTHER SAFETY INSTRUCTIONS AND GUIDELINES!

- Use only professional paintball fields where codes of safety are strictly enforced.
- Use compressed air/nitrogen only. Do not use any other compressed gas or pressurised liquid including CO².
- Always follow instructions, warnings and guidelines given with any first stage regulator you use with the GEO3.1.
- Use 0.68 inch calibre paintballs only.
- Always measure your marker's velocity before playing paintball, using a suitable chronograph.
- Never shoot at velocities in excess of 300 feet (91.44 meters) per second, or at velocities greater than local or national laws allow.
- Any installations, modifications or repairs should be carried out by a qualified individual at a licensed and insured paintball facility.



This Users Manual is in English. It contains important safety guidelines and instructions. Should you be unsure at any stage, or unable to understand the contents of this manual you must seek expert advice.



Le mode d'emploi est en Anglais. Il contient des instructions et mesures de sécurité importantes. En cas de doute, ou s'il vous est impossible de comprendre le contenu du monde d'emploi, demandez conseil à un expert.



ESTE MANUAL DE USUARIOS (oPERARIOS) usuarios está en Inglés. Contiene importantes normas de seguridad e instrucciones. Si no está seguro de algún punto o no entiende los contenidos de este manual debe consultar con un experto.



Diese Bedienungs - und Benutzeranleitung ist in Englisch. Sie enthält wichtige Sicherheitsrichtlinien und -bestimmungen. Sollten Sie sich in irgendeiner Weise unsicher sein, oder den Inhalte dies Heftes nicht verstehen, lassen Sie sich bitte von einen Experten beraten.

THIS USER MANUAL MUST ACCOMPANY THE PRODUCT IN THE EVENT OF RESALE OR NEW OWNERSHIP. SHOULD YOU BE UNSURE AT ANY STAGE YOU MUST SEEK EXPERT ADVICE (SEE SERVICE CENTRES PAGE 66).

6 USING THE GEO3.1

Details on setting up the GEO3.1 and information on the user interface. This section is essential reading for everyone.

- 6 Factory Set-up Guide
- 7 Installing a 9V Battery
- 8 Switching On the GEO3.1
Switching Off the GEO3.1
Firing the GEO3.1
- 9 Using the Break Beam Sensor System
- 10 The GEO3.1 Navigation Console
- 11 Installing a Barrel
- 12 Trigger Adjustment
- 14 Attaching a Loader
- 15 The Gas Through Pipe
- 16 Installing a Preset Air System
- 18 Velocity Adjustment
- 19 Solenoid Flow Restrictor
- 20 Unloading the GEO3.1
- 21 Storage and Transportation
- 22 The User Interface
The Run Screen Layout
- 23 The BBSS Indicator
The AUX Out Indicator
- 24 The Sound Indicator
The Trigger Detection Indicator
- 25 The Lock Indicator
The Battery Level Indicator
The Game Timer
The Shot Counter
- 26 The Actual Rate Of Fire
The Peak Rate Of Fire
The Menu System

27 ADVANCED SET-UP

In depth information on setting up the GEO3.1.

- 27 Accessing the Menu System
Moving Around the Menu
Altering Parameters
- 28 The Menu System

- 29 PRESET - The Preset Menu
LOAD - The Load Preset Parameter
SAVE - The Save Preset Parameter
- 30 FIRE MODE - The Fire Mode Parameter
ROF CAP - The Rate of Fire Cap Parameter
BS ON ROF - The Maximum Rate of Fire Parameter
BS OFF ROF - Rate of Fire with BBSS Off Parameter
- 31 RAMP SETUP - The Ramp Set-up Menu
TYPE - The Ramp Type Parameter
RATE - The Linear Ramp Rate Parameter
- 32 SEMI SHOTS - The Ramp Start Parameter
KICK IN - The Ramp Kick-In Parameter
SUSTAIN - The Sustain Rate Parameter
RESTART - The Ramp Restart Parameter
- 33 TIMING - The Timing Menu
DWELL - The Dwell Parameter
FSD COMP - The First Shot Drop-off Compensation Parameter
FSD DLY - The First Shot Drop-off Delay Parameter
- 34 FILTER - The Filter Menu
DEBOUNCE - The Debounce Parameter
EMPTY - The Breech Empty Time Parameter
FULL - The Breech Full Time Parameter
- 35 PULL TM - The Trigger Pull Time Parameter
RELEASE TM - The Trigger Release Time Parameter
PULL PT - The Trigger Pull Point Parameter
RELEASE PT - The Trigger Release Point Parameter
Basic Trigger Filter Set-up
Advanced Trigger Filter Set-up
- 37 HARDWARE - The Hardware Menu
TRIGGER - The Trigger Parameter
SOLENOID - The Solenoid Power Parameter
SOUND - The Sound Parameter
TONES - The Tones Parameter
- 38 BACKLIGHT - The Backlight Parameter
RED LEVEL - The Backlight Red Level Parameter
GRN LEVEL - The Backlight Green Level Parameter
BLU LEVEL - The Backlight Blue Level Parameter
- 39 CONTRAST - The LCD Contrast Level Parameter
AUX OUT - The AUX Out Parameter
DBL CLICK - The Double Clicking Parameter
AUTO OFF - The Auto Off Parameter

- 40 TRAINING - The Training Parameter
SHOT COUNT - The Shot Count Menu
GAUGE - The Gauge Parameter
GAUGE MAX - The Gauge Max Parameter
- 41 GAME TIMER - The Game Timer Menu
GAME - The Game Timer Parameter
ALARM - The Alarm Parameter
START - The Start Parameter

42 MAINTENANCE

A guide to cleaning and performing routine maintenance on specific areas of the GEO3.1.

- 42 The Break Beam Sensor System
- 44 The SL4 Inline Regulator Assembly
- 46 Advanced Inline Regulator Maintenance
- 47 Cleaning the Body Filter
- 48 Maintaining the Bolt System
- 50 Advanced Bolt System Maintenance
- 51 Removing the Frame
- 52 Attaching the Frame
- 53 Maintaining the SFR
- 54 The Trigger Assembly
- 56 The GEO3.1 Solenoid Assembly
- 59 The Push On Purge System

61 FAULT FINDING

Information on how to resolve any problems that might arise with your GEO3.1.

66 SERVICE CENTRES

Information on the location of your nearest Eclipse Service Centre.

67 TECHNICAL RESOURCES

Illustrated diagrams and component lists for key areas of the GEO3.1.

- 67 Operational Overview
- 68 GEO3.1 Parts List
- 70 Eclipse Shaft4 Barrel
- 71 SL4 Inline Regulator Assembly

- 72 GEO3.1 Bolt System
- 73 GEO3.1 Solenoid Assembly
- 74 GEO3.1 Push On Purge System (POPS) Assembly
- 75 Trigger Assembly
Clamping Feed Tube Assembly
- 76 GEO3.1 Circuit Board
- 77 Common Screw Size Chart
- 78 Common O-ring Size Chart

79 MENU TREE

A quick reference guide to the user interface.

83 ECLIPSE E-PORTAL

Information on the Eclipse E-Portal upgrade for GEO3.1.

84 INDEX

GEO3.1 Manual Index

WARRANTY CARD

Tear-out product registration card to be completed and returned. Alternatively register online at www.planeteclipse.com

FACTORY SET-UP GUIDE

⚠ WARNING ⚠

DE-GAS YOUR MARKER, DISCHARGING ANY STORED GAS IN A SAFE DIRECTION, AND REMOVE THE BARREL, LOADER, AIR SYSTEM AND ANY PAINTBALLS TO MAKE THE MARKER EASIER AND SAFER TO WORK ON.

Before using the GEO3.1 it is important to make sure the SL4 inline regulator, solenoid flow restrictor (SFR) and all electronically controlled parameters are set correctly. All of these can have a negative effect on the performance of the marker if set incorrectly.

The steps below will restore the GEO3.1 settings to the factory settings. These settings will give the GEO3.1 a more balanced performance, ideal for the average user.

INLINE REGULATOR OUTPUT PRESSURE

Check the inline regulator adjuster screw is set to $4\frac{1}{2}$ turns clockwise from its maximum out position (SEE FIGURE 1A). This will ensure the SL4 inline regulator is set to an output pressure that will not damage the GEO3.1 when supplied with compressed air/nitrogen (see page 18 for more information on SL4 inline regulator adjustment).

SOLENOID FLOW RESTRICTOR SETTINGS

Check that the solenoid flow restrictor (SEE FIGURE 1B) is set as pictured. See page 19 for more information on the solenoid flow restrictor.

ELECTRONICALLY CONTROLLED PARAMETERS

Load the FACTORY preset (SEE FIGURE 1C) stored on the GEO3.1 circuit board. This preset will restore all the electronic parameters to their default settings. See page 29 on loading the FACTORY preset.




FIG 1A




FIG 1B



FIG 1C

INSTALLING A 9V BATTERY

Ensure that the GEO3.1 is switched off. Lay the marker on a flat surface in front of you with the feed tube furthest away and with the barrel pointing to the right.

Use a 5/64" (2mm) hex key to remove the two countersunk screws that hold the rubber grip onto the frame (SEE FIGURE 2A). Peel the grip to the right to expose the circuit board within the frame.

Remove the fitted battery by sliding your thumb or finger into the recess below the battery and levering the battery out of the frame (SEE FIGURE 2B).

DO NOT pull on the top of the battery to remove it as this can cause the battery terminals to bend and will result in a poor electrical connection.

Fit a 9-volt alkaline battery (type PP3, 6LR61 or MN1604) into the recess with the battery terminals away from you. The positive terminal should be on the right hand side, nearest to the front side of the frame (SEE FIGURE 2C).

Planet Eclipse recommends using a branded high quality alkaline 9V battery. Budget and rechargeable batteries may cause performance issues.

Ensure that all of the wires are within the recess of the frame and away from the trigger, micro-switch and OPTO sensors so as not to interfere with their operation. Replace the rubber grip and screw in the two countersunk screws.

DO NOT OVER-TIGHTEN THE GRIP SCREWS.



FIG 2A



FIG 2B



FIG 2C

SWITCHING ON THE GEO3.1

To switch on the GEO3.1 press the  button twice in quick succession, referred to elsewhere in this manual as 'double-clicking'. The GEO3.1 can also be switched on by pushing and holding the  button (SEE FIGURE 3A).¹

SWITCHING OFF THE GEO3.1

Press and hold the  button (SEE FIGURE 3A) until the display shows "TURN OFF". Release the  button and re-press it to turn off the GEO3.1. Alternatively double click the  button to enter the menu tree then press  to turn off the GEO3.1.¹

FIRING THE GEO3.1

WARNING

PLANET ECLIPSE ADVISES NOT TO DRY FIRE/SHOOT THE MARKER WITHOUT PAINTBALLS.

PROLONGED DRY FIRING MAY LEAD TO DAMAGE/WEAR OF THE INTERNAL COMPONENTS OF THE MARKER

Pull the trigger (LABELLED  IN FIGURE 3B) to fire the GEO3.1. The entire firing sequence is controlled electronically by the GEO3.1 circuit board, enabling any user to easily achieve high rates of fire.



FIG 3A



FIG 3B

¹The double clicking feature is user selectable, factory default is set to on. It can be turned off using the Double Click parameter in the Hardware menu (see page 39).

USING THE BREAK BEAM SENSOR SYSTEM

The Break Beam Sensor System, referred to elsewhere in this manual as 'BBSS' is used to detect when a paintball is ready to be fired from the GEO3.1. If no paintball is ready then the BBSS will inhibit the GEO3.1 from firing. This prevents the GEO3.1 from "chopping" paintballs that are not fully loaded into the marker.¹

To switch off the BBSS, press and hold the  button for 0.5 seconds (SEE FIGURE 4A). The BBSS indicator on the top right of the LCD will change from  (enabled) to  (disabled).

To switch the BBSS back on, press and hold the  button for 0.5 second. The indicator will change back to .

When the BBSS is enabled, the indicator will change depending upon whether the system has detected a ball or not. When no ball has been detected the indicator will look like this . When a ball has been detected the icon changes to look like this .

Additional features of the GEO3.1's Break Beam Sensor System are covered in full on page 23 of this operators manual.



FIG 4A

¹When the GEO3.1 is turned on, the BBSS is automatically enabled.

THE GEO3.1 NAVIGATION CONSOLE

At the rear of the GEO3.1 grip frame you will find the navigation console (SEE FIGURE 5A) which is used for:

- Turning the GEO3.1 on and off using the  button.
- Scrolling through menus with the  and  buttons.
- Selecting parameters to edit using the  button.
- Editing parameters using the  and  buttons.
- Turning the GEO3.1 BBSS on and off using the  button (push and hold).
- Resetting recorded values using the  button (push and hold).
- Controlling the game timer with the  button (quick push and release).
- Scrolling through the various run screens using the  button (quick push and release).



FIG 5A

WARNING

THE BACKLIGHT ON THE LCD DISPLAY TURNS OFF AFTER A PERIOD OF TIME. WHEN THIS HAPPENS THE MARKER IS STILL ON AND ABLE TO FIRE. TO ADJUST THE LCD BACKLIGHT SEE PAGE 38.

INSTALLING A BARREL

⚠ WARNING ⚠

MAKE SURE THE MARKER IS TURNED OFF AND THAT NO PAINTBALLS ARE IN THE MARKER OR LOADER BEFORE INSTALLING A BARREL.

Every GEO3.1 comes complete with an Eclipse Shaft4 barrel (see page 70). The bore size of the Shaft4 barrel back is engraved on the barrel back just in front of the body threads.

To install the Shaft4 barrel, firstly screw the barrel tip and barrel back sections together. The threads on the Shaft4 barrel tip are reverse threaded. To screw the two sections together, with the barrel pointing away from you, turn the barrel tip in a clockwise direction (SEE FIGURE 6A).

While pointing the GEO3.1 marker in a safe direction, insert the assembled Shaft4 barrel into the front of the GEO3.1 body and screw the Shaft4 barrel into the GEO3.1 (in a counter-clockwise direction). Continue to screw the Shaft4 barrel into the GEO3.1 body until the barrel becomes snug in the body (SEE FIGURE 6B). DO NOT over tighten the barrel.

Install a barrel blocking device over the barrel such as the Eclipse barrel sock¹ supplied with the GEO3.1 (SEE FIGURE 6C).² You have now installed the barrel.

¹The Eclipse Barrel Sock that comes with the GEO3.1 may differ from that pictured in this manual.

²Instruction on using the Eclipse Barrel Sock can be found on the Eclipse Barrel Sock warning label.



FIG 6A



FIG 6B



FIG 6C

TRIGGER ADJUSTMENT

The GEO3.1 provides the user with the option to use either a micro-switch or an OPTO sensor (default OPTO) as the means for detecting trigger pulls. Before you begin to adjust and set your trigger, you must first select the method of trigger detection that you wish to use by entering the main menu and making your selection from the hardware menu (see page 37).

There are five adjustment points on the trigger – the front stop screw, the rear stop screw, the magnet return strength screw, the micro-switch activation screw and the spring return strength screw.

Figure 7A Key

- Ⓐ - Trigger leaf spring
- Ⓑ - Spring return strength screw
- Ⓒ - Trigger pin retaining screw
- Ⓓ - Front stop screw
- Ⓔ - Magnet return strength screw
- Ⓕ - Micro-switch activation screw
- Ⓖ - Rear stop screw
- Ⓗ - OPTO sensor activation prong

The front stop screw is used to set the amount of trigger travel prior to the marker firing. Turn this screw clockwise to reduce the amount of travel. Do not turn the screw too far or the trigger will be pushed past the firing point and the marker will not fire. Turn this screw counter-clockwise to increase the amount of trigger travel (SEE FIGURE 7B).

The rear stop screw is used to set the amount of travel after the marker has fired. Turn this screw clockwise to reduce the amount of travel. Do not turn the screw too far or the trigger will be prevented from reaching its firing point and the marker will not work. Turn this screw counter-clockwise to increase the amount of travel (SEE FIGURE 7C).




FIG 7A



FIG 7B




FIG 7C

CONTINUED

The magnet return strength screw is used to adjust the amount of force with which the trigger is returned to its rest position by the magnet. Turn the screw clockwise to increase the amount of force. Do not turn the screw too far or it will negate the position of the front stop screw. Turn the screw counter-clockwise to reduce the amount of force. Do not turn the screw too far or there may not be enough force to return the trigger (SEE FIGURE 7D).

The micro-switch activation screw is used to adjust the point in the trigger pull at which the micro-switch is activated (only if the Trigger parameter on page 37 is set to 'SWITCH'). Turn the screw clockwise to decrease the amount of trigger travel to the activation point. Turn the screw counter-clockwise to increase the amount of trigger travel to the activation point (SEE FIGURE 7E). Do not set the micro-switch activation screw too far out when using the OPTO sensors, as the screw can stop against the micro-switch before the trigger prong enters the OPTO sensors.

The spring return strength screw is used to adjust the spring strength that returns the trigger to its resting position. Turn the screw clockwise to increase the amount of spring return strength in the trigger pull. Turn this screw counter-clockwise to reduce the amount of spring return strength in the trigger pull. Do not turn the screw too far counter-clockwise or there will not be enough force to return the trigger consistently (SEE FIGURE 7F).

When setting the trigger it is important to ensure that the electronic trigger detection is working correctly. When the trigger is fully depressed the Trigger Detection Indicator (TDI) should point upwards   . When the trigger is fully released the TDI should point downwards   .

For more information, see understanding the Trigger Detection Indicator (TDI) on page 24 and the Filter menu on pages 34-36.



FIG 7D



FIG 7E



FIG 7F

ATTACHING A LOADER

⚠ WARNING ⚠

DO NOT OVER TIGHTEN THE CLAMPING FEED TUBE AS THIS MAY DAMAGE THE LOADER OR FEED TUBE ITSELF.

Using a 5/32" hex key or your fingers, turn the sprocket screw of the clamping feed tube counter-clockwise (SEE FIGURE 8A).

Release the clamping lever on the feed tube (SEE FIGURE 8B) and test to see if your loader can easily be pushed into the top of the feed tube. If the loader cannot easily be pushed into the feed tube, loosen the sprocket screw of the clamping feed tube a little more by turning it counter-clockwise using a 5/32" hex key or your fingers (SEE FIGURE 8A).

When you have managed to push your loader into the clamping feed tube, close the clamp to secure it firmly in place (SEE FIGURE 8C). If the loader is loose then you will need to release the clamp, tighten the sprocket screw slightly by turning it clockwise with a 5/32" hex key or your fingers and close the clamp. Repeat this process as necessary to secure your loader in place.

You have now attached a loader to your GEO3.1. Once you have filled your loader and air tank you will then be ready to begin using your GEO3.1.



THE GAS THROUGH PIPE

⚠ WARNING ⚠

IF THE GAS PIPE ASSEMBLY IS NOT CORRECTLY INSTALLED HIGH PRESSURE GAS WILL BE EMITTED.

DO NOT REMOVE THE GAS THROUGH PIPE WHEN THE MARKER IS PRESSURISED.

THERE IS NO NEED TO UNSCREW OR REMOVE THE GAS PIPE ASSEMBLY DURING DAY TO DAY USAGE OF THE MARKER.

Compressed gas is transferred from the frame to the inline regulator via gas pipe assembly (SEE FIGURE 9A), comprising of a gas pipe section¹ A and pipe nut section B. It is essential that this gas pipe assembly is correctly installed before the marker is supplied with compressed gas.

Before installing the gas pipe assembly, firstly inspect the o-rings on the pipe for any debris or damage (LABELLED C FIGURE 9A). Cleaning or replacing as necessary. Also inspect the receiver holes in the frame (SEE FIGURE 9B) and SL4 inline regulator (SEE FIGURE 9C) for any debris or dirt, cleaning as necessary.

Screw the pipe section into the nut section fully before attempting to install the gas pipe assembly in the marker (SEE FIGURE 9D). Insert the o-ring end of the pipe nut section into the SL4 regulator swivel (SEE FIGURE 9E). Rotate the swivel and gas pipe assembly to align the gas pipe section with the gas port in the frame.

Holding the pipe nut section in place inside the SL4 regulator swivel, screw the gas pipe section clockwise to extend it into the frame (SEE FIGURE 9F). If the gas pipe assembly can slide backwards and forwards, then the pipe is not fully installed and needs to be extended further.

The gas pipe only needs to be removed for maintenance procedures that require removal of the SL4 inline regulator or the frame assembly.



FIG 9A




FIG 9B

FIG 9C



FIG 9D



FIG 9E

FIG 9F

¹The GEO3.1 and EGO GEO3.1 gas pipe sections are not interchangeable.

⚠ WARNING ⚠

MAKE SURE THE MARKER IS TURNED OFF WITH A BARREL BLOCKING DEVICE INSTALLED AND THAT NO PAINTBALLS ARE IN THE MARKER OR LOADER BEFORE INSTALLING AN AIR SYSTEM.

COMPRESSED AIR AND NITROGEN SYSTEMS CAN BE EXTREMELY DANGEROUS IF HANDLED OR USED INCORRECTLY.

ONLY USE AN AIR SYSTEM CERTIFIED FOR USE WITHIN THE TERRITORY OF INTENDED USE.

THE GEO3.1 CANNOT BE USED WITH CO2. ONLY USE COMPRESSED AIR OR NITROGEN.

NEVER ADD ANY LUBRICANTS OR GREASES INTO THE FILL ADAPTER OF THE AIR SYSTEM REGULATOR

ENSURE THAT ALL SCREWS ARE TIGHTENED AND NO PARTS ARE LOOSE BEFORE INSTALLING AN AIR SYSTEM.

DO NOT PRESSURISE THE GEO3.1 WITHOUT THE BOLT SYSTEM CORRECTLY INSTALLED, AS HIGH PRESSURE GAS WILL BE EMITTED.

DO NOT INSTALL A COMPRESSED AIR SYSTEM OR LOAD PAINTBALLS INTO THE GEO3.1 UNTIL YOU FEEL COMPLETELY CONFIDENT WITH YOUR ABILITY TO HANDLE THE MARKER SAFELY AND RESPONSIBLY.

ALWAYS RELIEVE ALL RESIDUAL GAS PRESSURE FROM THE GEO3.1 BEFORE UNSCREWING THE PRESET AIR SYSTEM.

CHECK THAT THE GAS THROUGH PIPE ASSEMBLY IS CORRECTLY INSTALLED BEFORE INSTALLING A PRESET AIR SYSTEM.

SEE PAGE 15 FOR INSTRUCTION ON INSTALLING THE GAS THROUGH PIPE ASSEMBLY.



IF YOU ARE AT ALL UNSURE ABOUT INSTALLATION OF THE GAS THROUGH PIPE PLEASE CONTACT YOUR NEAREST SERVICE CENTRE

CONTINUED

Every GEO3.1 comes complete with an Eclipse push on purge system (POPS) which provides a direct connection for a preset air system. Before screwing an air system into the POPS ensure that the bonnet is disengaged in its forward position (SEE FIGURE 10A). If the bonnet is engaged, depress the latch button and slide the bonnet forward.

Check that the POPS retaining screws are tight. If the POPS can be moved on the frame the screws are too loose. Use a 5/32" hex key to tighten the screws.

Screw the preset air system into the POPS (SEE FIGURE 10B) so that the bottle screws in all the way and is tight.

Pull the bonnet backwards allowing the POPS pin to depress the valve pin in the preset air system causing the GEO3.1 to become pressurised (providing that there is sufficient air in your tank) (SEE FIGURE 10C). When the bonnet has been pulled back far enough it engages with the POPS body.^{1,2}

You have now installed a preset air system onto your GEO3.1.



FIG 10A



FIG 10B



FIG 10C

¹High, mid and low pressure output preset air systems can be used with the GEO3.1, providing the GEO3.1 has the SL4 inline regulator originally supplied with the marker.

²The force needed to engage the bonnet may vary depending on the output pressure and internal design of the air system being used.

VELOCITY ADJUSTMENT

When using your GEO3.1, you may wish to change the velocity at which your GEO3.1 is firing. This is done by inserting a 1/8" hex key into the adjuster screw at the bottom of your GEO3.1 inline regulator and adjusting it accordingly (SEE FIGURE 11A). By turning this adjuster screw clockwise you decrease the output pressure of the inline regulator and consequently the velocity; by turning the adjuster screw counter-clockwise you increase the output pressure of the inline regulator and consequently the velocity. On the bottom of the inline regulator sleeve there are arrows to illustrate which direction to turn the hex key to make the relevant adjustment.^{1,2,3}



¹After each adjustment fire two clearing shots to gain an accurate velocity reading. Never exceed 300fps.

²High, mid and low pressure output preset air systems can be used with the GEO3.1, providing the GEO3.1 has the SL4 inline regulator originally supplied with the marker.

³Turning the SL4 adjuster screw in too far will prevent the GEO3.1 from firing.

FIG 11A

SOLENOID FLOW RESTRICTOR

⚠ WARNING ⚠

**SETTING THE RESTRICTOR TOO LOW (ESPECIALLY IN EXTREME WEATHER CONDITIONS) MAY RESULT IN; LOW VELOCITY, INCONSISTENT VELOCITY OR PREVENTING THE BOLT FROM CYCLING.
IF THIS OCCURS INCREASE THE SFR FLOW SETTING.**

The following section covers direct adjustment of the solenoid valve which should only be used by users with a sound knowledge of the GEO3.1 firing cycle.

Built into the left side of the frame is the solenoid flow restrictor “SFR” (SEE FIGURE 12A), which controls the exhaust flow from the bolt system through the solenoid valve. By controlling the exhaust flow from the bolt system, the speed of the bolt during the forward stroke can be sped up or slowed down. The SFR can be adjusted using a 5/64” hex key.

The restrictor has a 90° range of adjustment from minimum to maximum flow.

By setting the restrictor to different levels of flow the user can control how the gun performs and feels when firing the marker.

Setting the restrictor to a higher level of flow will allow for higher cycles per second (dependent on the ROF Cap, see page 30). However these higher settings will also reduce the smoothness of the firing cycle compared to setting the restrictor at a lower level of flow.¹

Setting the restrictor to a lower level of flow will increase the smoothness of the firing cycle, however reducing the flow also lowers the cycling rate of the GEO3.1.¹

¹The restrictor controls the forward stroke of the bolt. As such it has the ability to directly control the velocity of the paintball. It is strongly recommended to chronograph the GEO3.1 after adjusting the restrictor.

The SFR has a minimum and maximum exhaust flow setting.

The maximum exhaust flow setting can be achieved by turning the SFR dial counter-clockwise so it is pointed vertical. This will allow the bolt to move forwards at its fastest possible speed.

The minimum exhaust flow setting can be achieved by turning the SFR dial clockwise so it is pointed horizontal. This setting will apply the greatest restriction on gas exiting the marker, slowing down the bolt forward stroke.

The SFR can be set anywhere in between the minimum and maximum

In the event that you do not want this adjustability available on the marker, a blanking plug is provided. This plug has the same effect as having the SFR set to maximum flow.

To install the blanking plug. Push the SFR out of the right side of the frame using a small hex key or pick (SEE FIGURE 12B), then simply push in the blanking plug making sure it is flush with the frame.




FIG 12A



FIG 12B

UNLOADING THE GEO3.1

⚠ WARNING ⚠

ALWAYS KEEP THE ECLIPSE GEO3.1 POINTED IN A SAFE DIRECTION AND ENSURE ALL PERSONS WITHIN RANGE CONTINUE TO WEAR FACE PROTECTION, UNTIL MARKER IS COMPLETELY UNLOADED AND SAFE.

Securely attach a barrel blocking device such as the Eclipse Barrel Sock¹ (supplied with the GEO3.1) to the marker as shown in [FIGURE 13A](#).

Turn off the GEO3.1 electronics by holding down the  button on the back of the frame. When the screen turns off and the marker speaker emits the 'off' tone (if the Sound parameter is enabled), the marker has been turned off ([SEE FIGURE 13B](#)).

With the GEO3.1 pointing away from you. De-gas the marker by depressing the POPS latch button allowing the bonnet to slide forward and vent air. Only when the POPS has fully degassed the GEO3.1 marker, unscrew and remove the air system ([SEE FIGURE 13C](#)).

Open the clamping lever on the feed tube and slacken off the sprocket screw if necessary on the feed tube. Carefully pull the loader out of the feed tube ([SEE FIGURE 13D](#)).

Looking down the feed tube, check to see if there are any paintballs still in the breech, if there are, turn the marker upside down while still keeping the barrel facing away from any persons within firing range then tip out any paintballs within the breech ([SEE FIGURE 13E & 13F](#)).

Next remove the barrel blocking device, and unscrew the barrel ([SEE FIGURE 13G](#)). Remove any paintballs within the barrel. The Eclipse GEO3.1 has now been unloaded and is ready for storage.



FIG 13A

FIG 13B



FIG 13C

FIG 13D



FIG 13E

FIG 13F

FIG 13G

¹Instruction on using the Eclipse Barrel Sock can be found on the Eclipse Barrel Sock warning label.

STORAGE AND TRANSPORTATION

CAUTION: NEVER CARRY YOUR ECLIPSE GEO3.1 UN-CASED WHEN NOT ON A PLAYING FIELD. THE NON-PLAYING PUBLIC AND LAW ENFORCEMENT PERSONNEL MAY NOT BE ABLE TO DISTINGUISH BETWEEN A PAINTBALL MARKER AND A REAL FIREARM. FOR YOUR OWN SAFETY AND TO PROTECT THE IMAGE OF PAINTBALL, ALWAYS CARRY THE ECLIPSE GEO3.1 (OR ANY OTHER PAINTBALL MARKER) IN A SUITABLE MARKER CASE SUCH AS THE ONE IN WHICH IT WAS SUPPLIED.

Your Eclipse GEO3.1 must be clear of all paint and propellant during transportation or storage.

Make sure the Eclipse GEO3.1 marker is off.

Remove the barrel from the marker.

Make sure the marker is clean of any paint residue, dirt and moisture.

Store your Eclipse GEO3.1 in a clean, cool, dry place.

Keep your Eclipse GEO3.1 away from any unauthorized and unsafe users.

It may be a good idea to remove the battery when storing your Eclipse GEO3.1 to prevent unauthorized use.

Protect your Eclipse GEO3.1 from excessive heat during transportation.

When transporting a paintball marker by air, check with the airline regarding their policies on transporting paintball equipment as hold luggage before arriving at the airport.

Observe and obey all local and national laws concerning the transportation of paintball markers. For information concerning any of the laws in your area, contact your nearby law enforcement agency.

When shipping the Eclipse GEO3.1 for any reason, Planet Eclipse recommends using the case in which the marker was originally supplied to protect the marker against rough handling during transport.

THE USER INTERFACE

The GEO3.1 has a simple user interface through which all aspects of its electronic control system can be monitored and adjusted by means of the three push buttons and graphical LCD which comprise the navigation console.

THE RUN SCREEN LAYOUT

The root of the user interface is the run screen which is the screen that is displayed most often when the GEO3.1 is on. The run screen has five display functions and the user can scroll through these functions by repeatedly pressing the  button on the navigation console.

- > Game Timer
- > Shot Counter
- > Peak Rate of Fire Indicator
- > Actual Rate of Fire Indicator
- > Splash (marker logo²)

With the exception of the Splash, the run screen is vertically divided with the screen function displayed on the left and a series of status icons displayed on the right.

The SPLASH run screen will display the marker logo with a flashing / alternating backlight. The marker is still able to fire when this screen is displayed.

BREAK BEAM SENSOR
SYSTEM INDICATOR

AUX OUT INDICATOR


TRIGGER DETECTION
INDICATOR

SOUND INDICATOR

USER SELECTABLE
DISPLAY OPTION

LOCK INDICATOR

BATTERY LEVEL
INDICATOR



¹The layout of the run screen is correct at time of printing. However newer versions of the GEO3.1 software may have a different layout of the run screen from what is printed in this manual. You may find some icons have been added or removed entirely. If you are unsure about any icons which do not feature in the manual contact your local dealer/service centre or Planet Eclipse directly.

²The splash graphic can be modified to display custom graphics with the Eclipse E-portal software sold separately (see page 83 for more information on Eclipse E-portal).

THE BBSS INDICATOR

The BBSS is able to switch itself off in the event of a blockage or contamination preventing it from functioning correctly. In this instance, the BBSS will switch itself back on once the blockage is cleared and the correct operation can be resumed.

The BBSS indicator on the main screen is used to indicate the eight possible states of the BBSS as follows:



—BBSS enabled and ball detected
The GEO3.1 can be fired at the maximum rate of fire determined by the chosen firing mode.



—BBSS Enabled No Ball Detected
The GEO3.1 cannot be fired.



—BBSS Fault Has Been Cleared and Ball Detected
The system has been re-enabled. A ball is detected and the GEO3.1 can be fired at the maximum rate of fire determined by the chosen firing mode.



—BBSS Fault Has Been Cleared and no ball detected
The system has been re-enabled. No ball is detected so the GEO3.1 cannot be fired. To reset the BBSS icon, use the  button to switch off the BBSS and then back on again.



—BBSS Disabled
The GEO3.1 can be fired at a maximum rate of fire as set by the BS OFF ROF parameter (see page 30).



—BBSS Fault Detected
The system is disabled. The GEO3.1 can only be fired at a maximum rate of 2bps less than the maximum rate of fire, up to a maximum of 10 bps.



—BBSS ENABLED In Training Mode
The BBSS has been over-riden as the user has selected training mode. As the user has chosen to leave the BBSS on, the achievable rate of fire is limited by the firing mode.



—BBSS DISABLED In Training Mode
The BBSS has been over-riden as the user has selected training mode. As the user has chosen to turn the BBSS off, the achievable rate of fire is limited by the BS OFF ROF parameter (see page 30).

THE AUX OUT INDICATOR

The auxiliary socket on the GEO3.1 circuit board allows third party products such as loaders or RF transmitters to be interfaced to the GEO3.1.

The AUX out indicator is turned on and off via the AUX OUT parameter (see page 39).

There are two possible conditions that can be indicated:



—AUX OUT ENABLED
The AUX out is enabled. Each time the circuit board detects a valid trigger pull a signal will be sent to the AUX connector on the circuit board.



—AUX OUT DISABLED
The AUX out is disabled. No signal will be sent to the AUX connector on the circuit board.

THE SOUND INDICATOR

The sound indicator on the run screen is used to convey if the Sound parameter in the Hardware menu (page 37) is switched on or off.

There are two possible conditions that can be indicated:



SOUND ENABLED

The sound parameter is enabled. The GEO3.1 will make sounds when switched on and off and when the game timer alarms or times out.



SOUND DISABLED

The sound parameter is disabled. The GEO3.1 will not make any sounds.

THE TRIGGER DETECTION INDICATOR

In order for the trigger to be successfully operated it must first be released and then pulled. The trigger detection indicator (TDI) is used to indicate each of the possible trigger states.



OPTO SENSOR SELECTED, READING 0%

The GEO3.1 is configured to use the OPTO sensor to detect trigger pulls. The OPTO sensor is currently reading 0%, i.e. the trigger is fully released.



OPTO SENSOR SELECTED, READING BELOW RELEASE POINT

The GEO3.1 is configured to use the OPTO sensor to detect trigger pulls. The OPTO sensor is currently reading below the OPTO release point, i.e. the trigger is considered 'released'.



OPTO SENSOR SELECTED, READING 100%

The GEO3.1 is configured to use the OPTO sensor to detect trigger pulls. The OPTO sensor is currently reading 100%, i.e. the trigger is fully depressed.



OPTO SENSOR SELECTED, READING ABOVE PULL POINT

The GEO3.1 is configured to use the OPTO sensor to detect trigger pulls. The OPTO sensor is currently reading above the OPTO pull point, i.e. the trigger is considered 'pulled'.



OPTO SENSOR SELECTED, READING MID-RANGE

The GEO3.1 is configured to use the OPTO sensor to detect trigger pulls. The OPTO sensor is currently reading somewhere between the OPTO release point and the OPTO pull point, i.e. the trigger is half depressed.



MICRO-SWITCH Selected, ACTUATED

The GEO3.1 is configured to use the micro-switch to detect trigger pulls. The micro-switch is currently actuated, i.e. the trigger is pulled.



MICRO-SWITCH SELECTED, NOT ACTUATED

The GEO3.1 is configured to use the micro-switch to detect trigger pulls. The micro-switch is not currently actuated, i.e. the trigger is released.

From the factory the GEO3.1 will have the OPTO sensor enabled. The micro-switch can be enabled from the Hardware menu (see page 37).

THE LOCK INDICATOR

The GEO3.1 has a tournament lock which prevents the user from making changes to any parameter that affects the way in which the GEO3.1 shoots, without the need for tools. This feature is necessary in order to make the GEO3.1 legal for tournament play. To enable or disable the tournament lock see Accessing the Menu System on page 27.

When the lock is enabled the lock indicator will show a closed padlock .

When the lock is disabled the lock indicator will show an open padlock .

THE BATTERY LEVEL INDICATOR

The battery level indicator is used to show the state of the battery within the GEO3.1. When the battery is fresh the indicator will show a 'full' battery  and as the battery is drained, so will the indicator show the battery emptying. When the battery reaches a point at which the GEO3.1 will no longer function reliably, the indicator will start to flash. At this point the battery must be changed immediately.

As well as displaying the voltage level of the battery, the indicator also warns if the battery being used has an incorrect voltage to operate the electronics reliably. The icon for a battery with an incorrect voltage output is . If this icon is shown the battery must be replaced immediately.

THE GAME TIMER

When the game timer is shown on the run screen then it can be started by pressing the  button and the timer will start to count down. The game timer can also be configured to start on a trigger press with the start parameter (see page 41).

When the game timer reaches the alarm time the game timer will start to flash and the audible alarm will sound every second, provided that the sound parameter is on.

When the game timer reaches 00:00, GAME OVER will be displayed and the audible alarm will sound continually, provided that the sound parameter is set to 'on'.

To stop the game timer at any time press and hold the  button for 0.5 seconds.

To reset the game timer to its preset start time, push and hold the  button for 0.5 second. The game timer will also be reset whenever the GEO3.1 is switched off.




THE SHOT COUNTER

The shot counter will increment every time that the circuit board registers a trigger pull, regardless of whether the shot counter is displayed or not. When the shot counter is displayed on the run screen it can be reset to 0 by pressing and holding the  button for 0.5 seconds.

There is also an optional shot gauge that can be displayed on this run screen. The gauge counts down from a user adjustable number. To alter the gauge settings see page 40. The gauge is reset whenever the GEO3.1 is switched off or the  button is pressed.

The shot counter does not function when the GEO3.1 is in Training Mode (see page 40).



THE ACTUAL RATE OF FIRE

When the actual ROF is selected for display the run screen will look something like the screen to the right. The value displayed in the top left of the screen represents the number of full cycles completed in a second - the actual rate of fire over that second. The value below it is the maximum actual rate of fire that has been achieved. The graph below this number shows the actual rates of fire achieved over time where each bar represents the amount of pulls in that second. To reset the maximum, press and hold the  button for 0.5 second.



THE PEAK RATE OF FIRE

When the peak ROF is selected for display the run screen will look something like the screen to the right, which differs from the display of the actual ROF by the inclusion of the indicator 'PK'. The value displayed in the top left of the screen represents the maximum rate of fire that has been recorded over the last second. The value below it is the maximum peak rate of fire that has been achieved. The graph below this number shows the peak rates of fire achieved over time. To reset this maximum, press and hold the  button for 0.5 seconds.

The peak ROF is typically higher than the actual ROF as it is much easier to fire two shots in quick succession than it is to maintain a string over a longer period of time.




THE MENU SYSTEM

Behind the run screen is a structured menu system comprised of two layers of menus. Each menu contains a number of menu items and each menu item can either be a parameter or a branch to another menu. Branches have an animated graphic on the right of the display, whereas parameters have their current value.

On parameter screens a range bar will be displayed where there is a large scale of adjustability in that parameter. The current parameter value is displayed as a box on the range bar which is used to indicate the range of adjustability in the parameter value.

At the bottom of the parameter screen the unit for that parameter will be displayed. Some parameters will not have units, such as on or off parameters.



ACCESSING THE MENU SYSTEM

To access the Main menu from the run screen double-click the  button and the first item on the Main menu will be displayed. Alternatively, push and hold the  button for 2 seconds.

Some of the parameters in the menu system can have a tournament lock applied to them. This lock can be toggled on and off by pressing the tournament lock button on the circuit board (SEE  A IN FIGURE 14A).

When trying to select a parameter that is locked, the a 'LOCKED' message will be briefly displayed.



FIG 14A

MOVING AROUND THE MENUS

WARNING THE MARKER CAN BE FIRED WHILE NAVIGATING ALL MENUS AND PARAMETERS.

Press and release the  button to display the next item on the menu. When the last menu item is displayed, pressing the  button will display the first item.

Press and release the  button to display the previous item on the menu. When the first menu item is displayed, pressing the  button will display the last item.

When the displayed item is a branch, as indicated by an animation on the right of the screen, press the  button to move to another menu.


ALTERING PARAMETERS

When the displayed item is a parameter, as indicated by a parameter value on the right of the screen, pressing the  button will activate the EDIT mode which allows the parameter value to be altered. When EDIT mode is active, the black box surrounding the parameter name disappears. There are two types of parameter, numeric parameters and choice parameters.

A numeric parameter has a numeric value whereas a choice parameter is one that has a small number of distinct choices. Altering parameter values is essentially the same for both types of parameter. To alter a numeric parameter, first activate the EDIT mode. Press the  button to increase the parameter value one step at a time. Press and hold the  button to increase the parameter value rapidly. When the value reaches its maximum it will revert to its minimum value. Press the  button to decrease the parameter value one step at a time. Press and hold the  button to decrease the parameter value rapidly. When the value reaches its minimum it will revert to its maximum value. When the required parameter value is displayed press the  button to accept the value and end the EDIT mode.

To alter a choice parameter, first activate the EDIT mode. Press the  button to display the next choice in the list. When the last choice is displayed, pressing  will display the first choice in the list. Press the  button to display the previous choice in the list. When the first choice is displayed, pressing the  button will display the last choice in the list. When the required choice is displayed press the  button to accept the choice and end the EDIT mode. If the displayed choice is cancel then pressing the  button will end the EDIT mode and restore the parameter to the value that is was prior to editing.





The Main menu contains both editable parameters and sub-menus which contain editable parameters. Some of these parameters affect the way the GEO3.1 shoots and are tournament locked as standard from the factory.¹

The Main menu also contains the TURN OFF option. Selecting this option will immediately turn off the GEO3.1, preventing it from firing.

Parameters followed by a * are part of the Smart Menu System and will only be displayed depending on your chosen settings. (e.g. The BS ON ROF parameter will only become available if the ROF CAP parameter is set to on).

¹The layout of the Main menu is correct at time of printing. However newer versions of the GEO3.1 software may have a different layout of the Main menu, sub-menus and parameters from what is printed in this manual. You may find some parameters have been added or removed entirely. If you are unsure about any parameters which do not feature in the manual contact your local dealer/service centre or Planet Eclipse directly.

PRESET MENU

In order to simplify the set up of the GEO3.1 a number of preset configurations are available for selection. Choosing one of these presets will cause all of the necessary parameters to be set in such a way as to make the GEO3.1 comply with the rules governing a particular paintball league¹. It is also possible for the user to save up to two preset configurations of their own.



LOAD PARAMETER

This parameter is used to load the required preset configuration and has the following choices:

- > USER 1: Load a set of custom firing mode parameters that have been previously saved by the user.
- > USER 2: Load a set of custom firing mode parameters that have been previously saved by the user.
- > FACTORY: Reset every parameter to the factory set default. The GEO3.1 leaves the factory set in this way.
- > NPPL: Load a set of parameters that configures the GEO3.1 to comply with the NPPL rules governing firing modes.^{1,2}
- > PSP 10: Load a set of parameters that configures the GEO3.1 to comply with the PSP rules governing firing modes in lower divisions (10bps).^{1,2}
- > PSP 12: Load a set of parameters that configures the GEO3.1 to comply with the PSP rules governing firing modes in higher divisions (12bps).^{1,2}
- > MS10: Load a set of parameters that configures the GEO3.1 to comply with the 2010 Millennium Series rules governing firing modes.^{1,2}
- > Cancel: Editing is cancelled and the parameter remains unchanged.



SAVE PARAMETER

This parameter is used to save the current set of parameters as a user defined custom preset configuration.

This parameter has the following choices:

- > USER 1: Save the current parameters as the preset 'USER 1'.
- > USER 2: Save the current parameters as the preset 'USER 2'.
- > CANCEL: Editing is cancelled and the parameter remains unchanged.



¹Some presets and fire modes may only be available in certain countries and on some models of the GEO3.1.

²All presets are correct at time of printing. It is the users responsibility to ensure that the loaded preset complies with the event rules the marker is intended to be used in.

FIRE MODE PARAMETER

This parameter is used to select the firing mode of the GEO3.1 and has the following choices:

- > Semi: This is the default and in this firing mode the GEO3.1 will fire one shot for every trigger pull.
- > RAMP: In this firing mode, the rate of fire is increased above the rate at which the trigger is pulled once certain criteria have been met. These criteria are set by the parameters on the Ramp Setup menu.¹
- > CANCEL: Editing is cancelled and the parameter is unchanged.

¹Some presets and fire modes may only be available in certain countries and on some models of the GEO3.1.

ROF CAP PARAMETER

The ROF CAP parameter is used to specify whether or not the GEO3.1 should have a limited / capped rate of fire. When the ROF CAP is enabled (and the BBSS is enabled), the maximum achievable rate of fire is set by the BS ON ROF parameter. Choices for the ROF CAP parameter are:

- > OFF: Rate of fire only limited by the loader.
- > ON: Rate of fire limited to the BS ON ROF parameter value.
- > CANCEL: Cancel editing and leave the parameter unchanged.

BS ON ROF PARAMETER*

The BS ON ROF parameter is used to set the maximum achievable rate of fire from the GEO3.1. The value of this parameter can be adjusted between 4.0 and 30.0 balls per second in 0.1bps increments.¹

The BS ON ROF parameter will only be displayed if you have set the ROF CAP parameter to 'ON'.

¹Always calibrate your GEO3.1 ROF CAP parameters to the local field BPS meter as readings may vary from meter to meter.

BS OFF ROF PARAMETER

The BS OFF ROF parameter is used to control how fast the GEO3.1 cycles when the Break Beam Sensor System is disabled. This parameter can be set between 4.0 and 15.0 balls per second and should always be set to the slowest speed of the loading system in use.¹

¹Always calibrate your GEO3.1 ROF CAP parameters to the local field BPS meter as readings may vary from meter to meter.



RAMP SETUP MENU

This menu is only available when ramping has been selected with the FIRE Mode parameter and comprises a list of parameters that control the way in which the GEO3.1 ramps, as shown below.

TYPE PARAMETER

This parameter is used to select the ramping style and has the following choices:

> STEP: Step ramping will cause the GEO3.1 to shoot in semi-automatic until a number of trigger pulls, set by SEMI SHOTS, have been made at a minimum pull rate, set by KICK IN. At this point the rate of fire will step up to the maximum rate of fire as set by BS ON ROF (or the maximum loader speed if the ROF CAP parameter is set to off). Ramping is maintained as long as the user continues to pull the trigger at a required rate set by SUSTAIN.

> LINEAR: Linear ramping will cause the GEO3.1 to shoot in semi-automatic until a number of trigger pulls, set by SEMI SHOTS, have been made at a minimum pull rate, set by KICK IN. At this point the rate of fire will equal the rate of trigger pulls increased by the percentage specified by RATE up to a maximum rate of fire as set by BS ON ROF, if the ROF CAP is on. Ramping is maintained as long as the user continues to pull the trigger at a required rate set by SUSTAIN.


> CANCEL: Editing is cancelled and no changes are made to the parameter.

RATE PARAMETER*

The parameter is only available when LINEAR ramping is selected and is used to set the percentage increase in rate of fire over rate of trigger pulls.

For example, if the user is pulling the trigger at a rate of 10 pulls per second and the RATE parameter is set to 50% then the rate of fire is 10 plus 50% extra which is 15 balls per second.

This parameter can be set between 0 and 100% in 10% increments.



SEMI SHOTS PARAMETER

The parameter sets the number of shots in semi-automatic that are required at the KICK IN rate before ramping will start. The parameter can be set between 3 and 9 pulls in 1 pull increments.



KICK IN PARAMETER

This parameter sets the minimum rate at which the user has to pull the trigger in order to start ramping. This parameter can be set between 3.3 and 10.0 pulls per second in 0.1 pulls per second increments.



SUSTAIN PARAMETER

Once the GEO3.1 is ramping the user has to continue to pull the trigger at a minimum rate in order to maintain the ramping. This parameter sets this rate and can be between 3.3 and 10.0 pulls per second in 0.1 pulls per second increments.



RESTART PARAMETER

The RESTART parameter defines the amount of time after the last trigger pull during which the ramp can be restarted with a single trigger pull. If a trigger pull occurs after the RESTART time has expired, then the other ramp start conditions have to be met before ramping will restart. This parameter can be set between 0.0 and 1.0 seconds in 0.1 second increments.




TIMING MENU

These parameters all relate to the control of the solenoid valve.




DWELL PARAMETER

The DWELL parameter sets the amount of time that the solenoid is energized and therefore the amount of gas that is released with each shot of the GEO3.1. Setting this parameter too low will result in low velocity shots and/or excessive shot to shot velocity fluctuations. Setting the parameter too high will simply waste gas and make the GEO3.1 louder. The DWELL can be set between 0.0 and 30.0 milliseconds. The factory default setting can normally be reduced after a few thousand shots as the GEO3.1 'beds-in'.



FSD COMP PARAMETER

"First shot drop off" is a reduction in velocity of the first shot fired after an extended period of not firing and is caused by the stiction between dynamic o-rings and the surfaces that they are in contact with. In order to compensate for first shot drop-off this parameter can be set to add extra time to the DWELL parameter for the first shot. This parameter can be set between 0.0 and 5.0 milliseconds.



FSD DLY PARAMETER

The time that has to elapse before the FSD COMP is applied to a shot following a previous shot. This parameter can be set between 00:00 and 04:00 minutes.



FILTER MENU

The parameters on the Filter menu are all used to tune the GEO3.1's software filters which prevent the GEO3.1 from firing unless all of the necessary conditions are met. The factory default settings will be suitable for most set-ups, however certain loader and trigger set-ups may require modification of one or more of these parameters.



DEBOUNCE PARAMETER

The DEBOUNCE parameter is used to combat any trigger bounce that might occur in the GEO3.1 and can be set between level 1 and level 9 in one level increments.

- > LEVEL 9: Level 9 providing the most filtering (least 'bouncy').
- > LEVEL 1: Level 1 providing the least filtering (most 'bouncy').
- > CANCEL: Cancel editing and leave the parameter unchanged.



EMPTY PARAMETER

In order for the BBSS to function correctly it must first detect that the bolt is fully retracted and the breech is empty, and then detect that a paintball is loaded into the breech before the GEO3.1 is allowed to fire. The parameter can be set between 1.0 and 20.0ms in 0.1ms increments.



FULL PARAMETER

Tumbling paintballs can take time to settle in the breech before they can be successfully fired. This parameter is used to set the amount of time that a paintball has to be in the breech before the GEO3.1 is allowed to fire. This parameter can be set between 1.0 and 20 milliseconds in 0.1ms increments.



PULL TM PARAMETER

The PULL TM parameter is used to set the minimum amount of time that the trigger must be pulled before it is recognised as a valid trigger pull. This parameter can be set between 3.0 and 20.0 milliseconds in 0.1ms increments.



RELEASE TM PARAMETER

The RELEASE TM parameter is used to set the minimum amount of time that the trigger must be released before it is recognised as a valid trigger release. This parameter can be set between 3.0 and 25.0 milliseconds in 0.1ms increments.




*PULL PT PARAMETER**

The PULL PT parameter is only available if OPTO has been selected in the Hardware menu. PULL PT defines the point at which the trigger is considered pulled and is adjustable between 51% and 99% in 1% increments.



*RELEASE PT PARAMETER**

The RELEASE PT parameter is only available if OPTO has been selected in the Hardware menu. RELEASE PT defines the point at which the trigger is considered released and is adjustable between 1% and 49% in 1% increments.



BASIC TRIGGER FILTER SET-UP

95% of trigger bounce problems can be eliminated by utilizing one of the nine fixed DEBOUNCE choices (LEVEL 1-9). In attempting to eliminate trigger bounce it is advisable to try the nine fixed DEBOUNCE choices before attempting any advanced set up of the trigger filters.

ADVANCED TRIGGER FILTER SET-UP

In order to optimize the trigger filters it is necessary to have the PULL PT parameter set as high as possible and the RELEASE PT parameter set as low as possible:

1. Select the PULL PT parameter. Observe that the graphical bar rises and falls as the trigger is pulled and released. The actual value of the graphical bar is displayed in the top right of the display.
2. Set the rear stop screw as required, ensuring that the bar is as close to 100% as possible when the trigger is fully depressed against the set screw. It is advisable to allow for some extra travel in the trigger pull once the bar has reached its maximum value.
3. Adjust the PULL PT parameter so that when the trigger is fully depressed the bar settles above the indicator on the left hand side of the screen (see page 35).
4. Select the RELEASE PT parameter. Observe that the graphical bar rises and falls as the trigger is pulled and released. The actual value of the graphical bar is displayed in the top right of the display.
5. Set the front stop screw as required, ensuring that the bar is as close to 0% as possible when the trigger is fully released against the set screw. It is advisable to allow for some extra travel in the trigger release once the bar has reached its minimum value.
6. Adjust the RELEASE PT parameter so that when the trigger is fully released the bar settles beneath the indicator on the left hand side of the screen (see page 35).
7. Set the magnet return strength screw and the spring return strength screw as required, making both the spring tension and the return force as strong as possible without compromising the "feel" of the trigger.

HARDWARE MENU

This menu comprises parameters that control low level functionality of the GEO3.1 electronic hardware.



TRIGGER PARAMETER

The GEO3.1 is fitted with a dual trigger pull detection system. A non-contact OPTO-electronic trigger sensor arrangement is used to detect trigger movement whilst a micro-switch is used to provide a more traditional tactile feedback for the trigger. The TRIGGER parameter is used to select which system is used. The choices available are as follows:

- > OPTO: Select the OPTO sensor for trigger pull detection.
- > SWITCH: Select the micro-switch for trigger pull detection.
- > CANCEL: Cancel editing and leave the parameter unchanged.



SOLENOID PARAMETER

This parameter controls the amount of power used by the solenoid valve and should normally be left at its default 'LO PWR' setting. Cold weather (sub 0°C/32°F) will cause lubricants to thicken and increase stiction in the marker system which may cause velocity drop-off and/or shot to shot inconsistency. Increasing the solenoid power will often help to eliminate these problems, but will cause more drain on the battery. The choices available for the parameter are:-

- > LO PWR: Low power solenoid drive
- > HI PWR: High power solenoid drive
- > CANCEL: Cancel editing and leave the parameter unchanged



SOUND PARAMETER

The GEO3.1 board is capable of emitting a variety of sounds to audibly signal when certain functions have been performed including, but not limited to, powering up, powering off, changing the BBSS mode and resetting various counters and timers. This parameter determines if this feature is switched on or off. Switching it on will cause increased drain on the battery. The choices available for this parameter are:

- >OFF: Sounds switched off.
- >ON: Sounds switched on.
- >CANCEL: Cancel editing and leave the parameter unchanged.



TONES PARAMETER*

This parameter determines if the GEO3.1 emits a tone each time any of the pushbuttons on the navigation console are activated. As part of the smart menu system the TONES parameter will only be shown in the Hardware menu if the SOUND parameter is switched 'ON'. The choices available for this parameter are:

- >OFF: Tones switched off.
- >ON: Tones switched on.
- >CANCEL: Cancel editing and leave the parameter unchanged.



BACKLIGHT PARAMETER

This parameter sets the time that the LCD backlight is illuminated after a pushbutton is pressed. The parameter can be set between 00:00 and 00:20 (20 seconds). If set to 00:00 then the backlight will not be illuminated.




*RED LEVEL PARAMETER**

This parameter sets the percentage of red light in the LCD backlight and can be set between 0% and 100% in 10% increments.



*GRN LEVEL PARAMETER**

This parameter sets the percentage of green light in the LCD backlight and can be set between 0% and 100% in 10% increments.



*BLU LEVEL PARAMETER**

This parameter sets the percentage of blue light in the LCD backlight and can be set between 0% and 100% in 10% increments.



CONTRAST PARAMETER

The parameter sets the contrast level of the LCD. This parameter is adjustable between 0 and 30 in increments of 1.



AUX OUT PARAMETER

This parameter turns on and off the AUX socket on the PCB. The choices available for this parameter are:

- >OFF: AUX socket switched off.
- >ON: AUX socket switched on.
- >CANCEL: Cancel editing and leave the parameter unchanged.



DBL CLICK PARAMETER

This parameter is used to select where double-clicking the  button can be used. The choices available for this parameter are:

- >NONE: Double clicking is disabled entirely. To power up the GEO3.1 and enter the Main Menu the user needs to push and hold the  button.
- >POWER UP: Double clicking only works when powering up the GEO3.1. To enter the Main Menu the user still needs to push and hold the  button.
- >ALL: Double clicking works when powering up the GEO3.1 and entering the Main Menu. Push and hold still works for these procedures as well.
- >CANCEL: Cancel editing and leave the parameter unchanged.



AUTO OFF PARAMETER

This parameter sets the time that has to elapse before the GEO3.1 switches itself off if not used. The parameter can be set between 05:00 and 20:00 minutes.



TRAINING PARAMETER

In training mode the GEO3.1 simulates the firing cycle so that the user may practice pulling the trigger without wasting air and making lots of noise. The BBSS is overridden in order to simulate paintballs entering the breech and the beeper indicates when a shot is fired. Training mode is indicated with a 'T' in the BBSS indicator.

- > OFF: Training mode is disabled and the GEO3.1 functions normally.
- > ON: Training mode is enabled.
- > CANCEL: Cancel editing and leave the parameter unchanged.



SHOT COUNT MENU

This menu is comprised of parameters that control the shot counter.



GAUGE PARAMETER

This parameter allows the user to toggle the gauge graphic on and off in the shot counter Run Screen. The choices for the GAUGE parameter are:

- > OFF: Gauge graphic on the shot counter run screen is disabled.
- > ON: Gauge graphic on the shot counter run screen is enabled.
- > CANCEL: Cancel editing and leave the parameter unchanged.



GAUGE MAX PARAMETER*

The gauge max parameter allows the user to set the number the gauge counts down from every time the GEO3.1 is fired. The user can set the gauge from 100 to 2000 in increments of 10.



GAME TIMER MENU

This menu is comprised of parameters that control the operation of the Game Timer.



GAME PARAMETER

This parameter is used to set the Game Time, the time from which the game timer counts down to zero. This parameter can be set between 00:00 and 60:00 minutes in 10 second increments. The factory default is 07:10 (7 minutes 10 seconds).

When the game timer reaches 00:00, GAME OVER will be displayed and the audible alarm will sound continually, provided that the SOUND parameter is set to 'ON'.



ALARM PARAMETER

An alarm condition is generated whenever the Game Timer counts down to the time set by the ALARM parameter. This parameter can be set between 00:00 and 10:00 minutes in 10 second increments.

When the alarm condition is generated the Game Timer will start to flash and the audible alarm will sound every second, provided that the SOUND parameter is set to 'ON'.



START PARAMETER

This parameter is used to select the event which will cause the Game Timer to begin counting down. This parameter has the following choices:

- > **BUTTON:** Pressing the  button will start the Game Timer.
- > **TRIGGER:** Pulling the trigger will start the Game Timer.
- > **CANCEL:** Cancel editing and leave the parameter unchanged.



THE BREAK BEAM SENSOR SYSTEM

⚠ WARNING ⚠

DE-GAS YOUR MARKER, DISCHARGING ANY STORED GAS IN A SAFE DIRECTION, AND REMOVE THE BARREL, LOADER, AIR SYSTEM AND ANY PAINTBALLS TO MAKE THE MARKER EASIER AND SAFER TO WORK ON.

Undo the retaining screw for the Break Beam Eye cover on the left hand side of the GEO3.1 using a 5/64" (2mm) hex key (SEE FIGURE 15A).

Remove the eye cover to expose the back of the Break Beam Sensor unit (SEE FIGURE 15B). Using a dry cotton bud, carefully remove any debris, paint or moisture from the back of the sensor unit and from inside the eye cover.

Lift the Break Beam Sensor unit free from the GEO3.1 body and using another dry cotton bud, remove any grease or debris build-up from the front of the sensor unit (SEE FIGURE 15C).



FIG 15A



FIG 15B



FIG 15C

(CONTINUED)

Remove the rubber detent and using a dry cotton bud clean the detent and its location point in the GEO3.1 body, replacing the detent if it is damaged (SEE FIGURE 15D).

Reinsert the detent back into the GEO3.1 body and place the BBSS back into the designated slot in the body (SEE FIGURE 15E). Ensure that the sensor is face down in the body i.e. looking into the breach.¹

Replace the eye cover and using a 5/64" hex key, replace the retaining screw to hold the eye cover in place (SEE FIGURE 15F).

Repeat the procedure for the opposite side of the GEO3.1.

You have now cleaned your Break Beam Sensor System.

¹Ensure that the receiver sensor (indicated by a red mark & red heat shrink) is located on the right-hand side of the marker body.

⚠ WARNING ⚠

IF YOU ARE UNSURE ABOUT PERFORMING A MAINTENANCE PROCEDURE PLEASE CONTACT YOUR NEAREST SERVICE CENTRE.



FIG 15D



FIG 15E



FIG 15F

THE SL4 INLINE REGULATOR ASSEMBLY

⚠ WARNING ⚠

DE-GAS YOUR MARKER, DISCHARGING ANY STORED GAS IN A SAFE DIRECTION, AND REMOVE THE BARREL, LOADER, AIR SYSTEM AND ANY PAINTBALLS TO MAKE THE MARKER EASIER AND SAFER TO WORK ON.

Unscrew and remove the gas pipe assembly from the SL4 inline regulator (SEE FIGURE 16A). See page 15 for more information on removing the gas pipe assembly.

Grip the SL4 inline regulator tightly through the rubber sleeve and unscrew the SL4 inline regulator from the GEO3.1 body (SEE FIGURE 16B). Pull the foregrip crown down to free it from the GEO3.1 body (SEE FIGURE 16C).

Inspect the o-ring at the top of the threads on the FRM for damage (LABELLED A) FIGURE 16D). Replace and re-lubricate as necessary.¹

Tip both the piston and spring out of the top of the inline regulator (SEE FIGURE 16E).

Insert a 1/8" hex key into the adjuster screw assembly in the bottom of the inline regulator, turn the adjuster screw clockwise through the inline regulator body (SEE FIGURE 16F & 16G), and push the adjuster assembly out of the top of the inline regulator body.²

Thoroughly clean the O11 NBR70 o-rings that sits on the outside of the adjuster assembly, then re-lubricate with Eclipse Grease (SEE FIGURE 16H).¹

Using a dry cotton bud, clean the internal O08 NBR70 o-ring that sits inside the top section of the adjuster top. Then using a small hex key gently apply Eclipse Grease to the o-ring (SEE FIGURE 16I).¹



FIG 16A



FIG 16B



FIG 16C



FIG 16D



FIG 16E



FIG 16F



FIG 16G



FIG 16H

¹If any o-rings are damaged then replace them. Extra o-rings are available in parts kits available at www.planeteclipse.com

²The adjuster screw can only be removed by turning it upwards through the bottom section of the inline regulator. The regulator will be damaged if the adjuster screw is removed incorrectly.

(CONTINUED)

Inspect the internal sealing surfaces of the regulator body, removing any dirt or debris with a cotton bud (SEE FIGURE 16J).

Re-install the adjuster assembly into the inline regulator body threaded end first. Apply light pressure to the top of the adjuster, while using a 1/8" hex turn the adjuster screw counter-clockwise until it stops at the base of the inline regulator body (SEE FIGURE 16K).


Take the piston, inspect for damage and clean the 14x2 NBR70 o-ring at the top. Re-lubricate it with a light application of Eclipse Grease (SEE FIGURE 16L). Place the inline regulator spring over the piston, then insert the piston and spring into the top of the inline regulator body (SEE FIGURE 16M).¹

To replace the foregrip crown, push the crown up onto the body until the FRM threads and body plug are covered (SEE FIGURE 16N).

Re-attach the inline regulator to the GEO3.1 FRM (SEE FIGURE 16O), then re-connect the gas pipe fitting (see page 15).

Basic cleaning of the SL4 inline regulator is complete.

Reset the input pressure to the factory default before supplying the GEO3.1 with compressed air.



¹If any o-rings are damaged then replace them. Extra o-rings are available in parts kits available at www.planeteclipse.com

⚠ WARNING ⚠

IF YOU ARE UNSURE ABOUT PERFORMING A MAINTENANCE PROCEDURE PLEASE CONTACT YOUR NEAREST SERVICE CENTRE.

ADVANCED INLINE REGULATOR MAINTENANCE

⚠ WARNING ⚠

DE-GAS YOUR MARKER, DISCHARGING ANY STORED GAS IN A SAFE DIRECTION, AND REMOVE THE BARREL, LOADER, AIR SYSTEM AND ANY PAINTBALLS TO MAKE THE MARKER EASIER AND SAFER TO WORK ON.

This procedure is only required if you are fixing a supercharging SL4 inline regulator (common symptoms of supercharging are a very high velocity first shot and/or large variances in shot to shot consistency).

Place a 3/32" hex key through the adjuster top (SEE FIGURE 17A), then insert a 1/8" hex key into the bottom of the adjuster screw and carefully turn it counter-clockwise until the two parts begin to unscrew freely (SEE FIGURE 17B). With your fingers fully unscrew the two parts taking care not to lose any of the internal components (SEE FIGURE 17C).

Inside the adjuster screw you will find a regulator seal, purge poppet and spring (purge poppet assembly) (SEE FIGURE 17D). Inspect and clean the regulator seal, turning it over if one side appears excessively worn or damaged or replace if necessary. Inspect and clean the purge poppet or replace if necessary.

Place the purge poppet and attached spring in the central hole in the regulator seal, then insert these parts into the adjuster screw (SEE FIGURE 17E). Ensure it is re-installed correctly, failure to do so may seriously damage the GEO3.1 solenoid.

With the regulator seal, purge valve and spring installed back into the adjuster screw, replace the adjuster top (SEE FIGURE 17F). Screw the two parts tightly together using 1/8" and 3/32" hex keys. Refer to the 'SL4 Inline Regulator Assembly' section on pages 44-45 to re-assemble the SL4 inline regulator.

⚠ WARNING ⚠

IF YOU ARE UNSURE ABOUT PERFORMING A MAINTENANCE PROCEDURE PLEASE CONTACT YOUR NEAREST SERVICE CENTRE.



FIG 17A



FIG 17B



FIG 17C



FIG 17D



FIG 17E



FIG 17F

CLEANING THE BODY FILTER

⚠ WARNING ⚠

DE-GAS YOUR MARKER, DISCHARGING ANY STORED GAS IN A SAFE DIRECTION, AND REMOVE THE BARREL, LOADER, AIR SYSTEM AND ANY PAINTBALLS TO MAKE THE MARKER EASIER AND SAFER TO WORK ON.

Remove the inline regulator as covered on page 44. Turn the GEO3.1 upside down to reveal the body filter inside the body (SEE FIGURE 18A).

Using a 5/64" hex key unscrew and remove the retaining screw (SEE FIGURE 18B).

Then remove the body filter (SEE FIGURE 18C).

Inspect and clean the body filter. If the filter is very dirty replace with a new filter.

Insert the filter¹ into the FRM on the GEO3.1 body, ensuring the hole in the filter lines up with the threads in the body (SEE FIGURE 18D).

Using a 5/64" hex key, replace the retaining screw. DO NOT over tighten the retaining screw as this may result in the filter being crushed between the screw and GEO3.1 body (SEE FIGURE 18E).

Re-attach the inline regulator to the GEO3.1.

If after cleaning the GEO3.1 is still experiencing slow purge and low velocity issues the filter may need replacing.

¹If the filter has only been cleaned and not replaced with a new one, ensure the filter is inserted back into the body facing the same way it was removed. This will prevent any dirt embedded in the filter being blow into the bolt system of the marker when supplied with compressed air.

⚠ WARNING ⚠

IF YOU ARE UNSURE ABOUT PERFORMING A MAINTENANCE PROCEDURE PLEASE CONTACT YOUR NEAREST SERVICE CENTRE.



FIG 18A



FIG 18B

FIG 18C



FIG 18D

FIG 18E

MAINTAINING THE BOLT SYSTEM

⚠ WARNING ⚠

DE-GAS YOUR MARKER, DISCHARGING ANY STORED GAS IN A SAFE DIRECTION, AND REMOVE THE BARREL, LOADER, AIR SYSTEM AND ANY PAINTBALLS TO MAKE THE MARKER EASIER AND SAFER TO WORK ON.

Using a 1/4" hex key or fingers unscrew the prop shaft from the marker body (SEE FIGURE 19A). Once the threaded section is free from the threads in the marker body and turning freely, pull the prop shaft from the marker body.

Place a finger down the feed tube and push the bolt into the bolt can inside the body by pushing it backwards (SEE FIGURE 19B). Insert a finger into the rear of the marker and remove the bolt and bolt can completely (SEE FIGURE 19C).

You have removed the following parts from the marker body: the prop shaft (A), the bolt can (B) and the bolt (C) (SEE FIGURE 19D).

Take the bolt can and having cleaned off any old grease, paint or debris, apply a small amount of Eclipse Grease to the two external o-rings (SEE FIGURE 19E) and the internal o-ring (SEE FIGURE 19F)¹.

Smear a light coat of Eclipse Grease onto the smooth internal bore of the bolt can from the rear (SEE FIGURE 19G).

Take the prop shaft and having cleaned off any old grease, paint or debris, apply Eclipse Grease to the large rear o-ring and the threads (SEE FIGURE 19H).



FIG 19A



FIG 19B



FIG 19C



FIG 19D



FIG 19E



FIG 19F



FIG 19G



FIG 19H

¹Remove any excess blobs of eclipse grease from the inside and outside of the bolt can.

(CONTINUED)

Then apply a small amount of Eclipse Grease to the 14x2 o-ring near the front of the prop shaft (SEE FIGURE 19I).

Take the bolt and having cleaned off any old grease, paint or debris. Examine the rubber bolt tip for an signs of damage (SEE FIGURE 19J), replacing if necessary.

Apply a light film of Eclipse Grease to the front end of the bolt and also the internal rear bore of the bolt (SEE FIGURE 19K & 19L). Apply a coat of Eclipse Grease to the two external bolt o-rings near the centre of the bolt (SEE FIGURE 19M).

REMOVE EXCESS ECLIPSE GREASE BY WIPING OFF WITH FINGER. AIM TO APPLY ONLY A VERY THIN FILM OF GREASE TO THE COMPONENTS MAINTAINED, AS EXCESS GREASE BOLT CAN CAUSE POOR PERFORMANCE.

Slide the bolt onto the prop shaft (SEE FIGURE 19N) and slide the bolt can over the bolt and push into place until the bolt can touches the prop shaft back cap (SEE FIGURE 19O).

Finally wipe any excess Eclipse Grease off the o-ring on the head of the bolt and insert the complete bolt assembly into the marker body.

Either by hand or using a 1/4" hex key, screw the bolt assembly into the marker body (SEE FIGURE 19P)¹. If screwed in by hand the prop shaft and bolt, can be accessed and maintained by hand in future.

¹DO NOT over tighten the Bolt Assembly.



WARNING

IF YOU ARE UNSURE ABOUT PERFORMING A MAINTENANCE PROCEDURE PLEASE CONTACT YOUR NEAREST SERVICE CENTRE.



FIG 19I



FIG 19J



FIG 19K



FIG 19L



FIG 19M



FIG 19N



FIG 19O



FIG 19P

ADVANCED BOLT SYSTEM MAINTENANCE

⚠ WARNING ⚠

DE-GAS YOUR MARKER, DISCHARGING ANY STORED GAS IN A SAFE DIRECTION, AND REMOVE THE BARREL, LOADER, AIR SYSTEM AND ANY PAINTBALLS TO MAKE THE MARKER EASIER AND SAFER TO WORK ON.

This procedure is only required if you are maintaining the rear prop shaft 14x2 o-ring, which if damaged or dirty will cause a leak around the back cap of the GEO3.1.

Insert an appropriately sized hex key or screw driver shaft into the hole in the middle of the prop shaft, take a 1/8" hex key and remove the retaining screw in the back of the prop shaft (SEE FIGURE 20A). Remove the prop shaft from the back cap, taking care not to lose the prop shaft spring. Check the 14x2 o-ring at the back of the prop shaft, and clean or replace then re-lubricate with Eclipse Grease as necessary (SEE FIGURE 20B).

Check the rear bumper for signs of wear, replace as necessary then re-install the spring (SEE FIGURE 20C). Replace the back cap over the rear of the prop shaft, then replace the retaining screw using a 1/8" hex key to reassemble to prop shaft (SEE FIGURES 20D & 20E).¹



FIG 20A



FIG 20B



FIG 20C



FIG 20D



FIG 20E

¹If any o-rings or the bumper are damaged then replace them. Extra o-rings and bumpers are available in parts kits available at www.planeteclipse.com

REMOVING THE FRAME

⚠ WARNING ⚠

DE-GAS YOUR MARKER, DISCHARGING ANY STORED GAS IN A SAFE DIRECTION, AND REMOVE THE BARREL, LOADER, AIR SYSTEM AND ANY PAINTBALLS TO MAKE THE MARKER EASIER AND SAFER TO WORK ON.

Removal of the frame is required for access to the solenoid assembly, trigger bearing carrier assembly and Break Beam Sensor System wires if maintenance on either is required.

Disconnect any hosing and unscrew the inline regulator from the Front Regulator Mount (FRM) as detailed in the 'Cleaning the inline regulator' section of this Maintenance Guide.

Using a 5/64" hex key, remove the four screws that attach the GEO3.1 rubber grips to the GEO3.1 frame (SEE FIGURE 21A).

Unplug the solenoid and the Break Beam Sensor System wiring harnesses from their respective ports on the GEO3.1 circuit board (SEE FIGURE 21B).

Using a 1/8" hex key, unscrew but DO NOT REMOVE the front frame screw located under the foregrip crown (SEE FIGURE 21C).

Using the short arm of a 1/8" hex key, loosen the rear frame screw 2-3 full turns (SEE FIGURE 21D).

Slide the frame backwards approximately half an inch so that the rear frame screw disengages from the frame and remove the frame from the GEO3.1 body taking care not to damage any wires (SEE FIGURE 21E).

You have now removed your GEO3.1 frame from the GEO3.1 body.

⚠ WARNING ⚠

IF YOU ARE UNSURE ABOUT PERFORMING A MAINTENANCE PROCEDURE PLEASE CONTACT YOUR NEAREST SERVICE CENTRE.



FIG 21A

FIG 21B



FIG 21C

FIG 21D



FIG 21E

ATTACHING THE FRAME

⚠ WARNING ⚠

DE-GAS YOUR MARKER, DISCHARGING ANY STORED GAS IN A SAFE DIRECTION, AND REMOVE THE BARREL, LOADER, AIR SYSTEM AND ANY PAINTBALLS TO MAKE THE MARKER EASIER AND SAFER TO WORK ON.

To install the frame, firstly check the SFR seal is correctly located in the top of the frame (SEE FIGURE 22A), then carefully thread the solenoid and the Break Beam Sensor System wiring harnesses through the access hole in the top of the frame and line the frame up so that the rear frame screw sits in the access hole (SEE FIGURE 22B).

Be careful not to trap or pinch the BBSS or solenoid wires between the body and frame.

Slide the frame forward so that it sits completely flush with the GEO3.1 body and using the short arm of a 1/8" hex key, tighten the rear frame screw into place (SEE FIGURE 22C). Check that no wires are trapped before tightening down the rear frame screw.

Once the rear frame screw is secure, insert a 1/8" hex key into the front frame screw hole in the foregrip crown and tighten the front screw into place (SEE FIGURE 22D).

Connect the solenoid and Break Beam Sensor System wiring harnesses to their respective ports on the GEO3.1 circuit board and (SEE FIGURE 22E). Adjust the wires so that they sit neatly in the grip frame and ensure that the wires do not obstruct either the micro-switch or the Opto sensor (SEE FIGURE 22F).


Attach the GEO3.1 rubber grips to the frame using a 5/64" hex key to replace the four grip screws (SEE FIGURE 22G).

Screw the inline regulator back into the Front Regulator Mount and connect any hosing that was disconnected earlier (SEE FIGURE 22H).

You have now re-installed the frame onto the GEO3.1.

⚠ WARNING ⚠

IF YOU ARE UNSURE ABOUT PERFORMING A MAINTENANCE PROCEDURE PLEASE CONTACT YOUR NEAREST SERVICE CENTRE.



MAINTAINING THE SFR

⚠ WARNING ⚠

DE-GAS YOUR MARKER, DISCHARGING ANY STORED GAS IN A SAFE DIRECTION, AND REMOVE THE BARREL, LOADER, AIR SYSTEM AND ANY PAINTBALLS TO MAKE THE MARKER EASIER AND SAFER TO WORK ON.

The stages below on SFR maintenance do not require the frame to be removed, and can be followed for SFR removal/ blanking plug installation.

Using a small hex key push the SFR body out of the left side of the frame (SEE FIGURE 23A).

Inspect and clean the SFR body and o-rings, making sure the hole through the centre of the SFR body is free of paint or debris (SEE FIGURE 23B).

Lastly make sure the pocket in the frame that houses the SFR and the exhaust port below are clean (SEE FIGURE 23C).

Next, insert the SFR body into the frame as shown in FIGURE 23D. Make sure the dial sits flush with the surface of the frame (SEE FIGURE 23E).

This last stage of maintenance requires the frame to be removed. It is only needed if the SFR is having little or no effect.

In the top of the frame locate and remove the SFR seal (SEE FIGURE 23F). Inspect and clean the seal, replacing if damaged or heavily worn.

Reinsert the SFR seal into the top of the frame, making sure the contoured face is exposed (SEE FIGURE 23G).

⚠ WARNING ⚠

IF YOU ARE UNSURE ABOUT PERFORMING A MAINTENANCE PROCEDURE PLEASE CONTACT YOUR NEAREST SERVICE CENTRE.



FIG 23A



FIG 23B



FIG 23C



FIG 23D



FIG 23E



FIG 23F



FIG 23G

THE TRIGGER ASSEMBLY

⚠ WARNING ⚠

DE-GAS YOUR MARKER, DISCHARGING ANY STORED GAS IN A SAFE DIRECTION, AND REMOVE THE BARREL, LOADER, AIR SYSTEM AND ANY PAINTBALLS TO MAKE THE MARKER EASIER AND SAFER TO WORK ON.

Having removed the frame completely from the GEO3.1 body (see page 51). Unscrew the two M2.5x5 retaining screws which hold the bearing carrier in the frame (SEE FIGURE 24A).

Gently lift the bearing carrier and trigger assembly free from the frame taking care not to damage the micro-switch or the OPTO sensors (SEE FIGURE 24B).

Remove the trigger spring from the bearing carrier, removing any paint or moisture (SEE FIGURE 24C).

Using a 1/16" hex key, loosen the trigger pin retaining set screw from the back of the trigger (SEE FIGURE 24D).

Use a small hex key to push the trigger pin out of the bearing carrier from one side (SEE FIGURE 24E), then remove the bearing carrier from the trigger (SEE FIGURE 24F).

Clean the trigger and bearing carrier thoroughly and also clean the space within the frame that the trigger sits in.



FIG 24A



FIG 24B



FIG 24C



FIG 24D



FIG 24E



FIG 24F

(CONTINUED)

Position the trigger so that the hole through the trigger lines up with the holes in the bearing carrier, slide the trigger pin into place (SEE FIGURE 24G).

Gently lower the trigger assembly and bearing carrier into the frame, taking care not to damage the micro-switch or the OPTO sensor, and ensuring that the trigger is positioned correctly (SEE FIGURE 24H).

Using a 5/64" hex key screw the right side M2.5x5 retaining screw into place but do not fully tighten it into place (SEE FIGURE 24I).

Ensure the trigger moves freely within the frame, then using a 1/16" hex key tighten down the trigger pin retaining set screw.

Place the trigger spring over the bearing carrier in its designated groove, align the hole in the trigger spring with the front/left hole in the bearing carrier, then screw the retaining screw into the frame. Tighten both screws with a 5/64" hex key (SEE FIGURE 24J).

DO NOT overtighten the retaining screws. Doing so may damage the trigger spring and threads in the frame.

You have now stripped and cleaned your GEO3.1 trigger assembly.



FIG 24G



FIG 24H



FIG 24I



FIG 24J

⚠ WARNING ⚠

IF YOU ARE UNSURE ABOUT PERFORMING A MAINTENANCE PROCEDURE PLEASE CONTACT YOUR NEAREST SERVICE CENTRE.

THE GEO3.1 SOLENOID ASSEMBLY

⚠ WARNING ⚠
DE-GAS YOUR MARKER, DISCHARGING ANY STORED GAS IN A SAFE DIRECTION, AND REMOVE THE BARREL, LOADER, AIR SYSTEM AND ANY PAINTBALLS TO MAKE THE MARKER EASIER AND SAFER TO WORK ON.

IMPORTANT

The GEO3.1 solenoid assembly contains two sub-assemblies, the solenoid valve and the solenoid manifold. Removal of the solenoid valve is required to access the solenoid manifold for servicing. The solenoid valve itself (SEE FIGURE 25A) is a non-serviceable item. Any attempt to strip or service the solenoid valve will immediately void the GEO3.1 warranty. If you experience any issue with the GEO3.1 solenoid valve then please contact your Eclipse Service Centre. See page 66 for Eclipse Service Centre details.

With the frame separated from the GEO3.1 body and the solenoid and BBSS wires unplugged from the circuit board (see page 51) use a 5/64" hex key to undo and remove the two screws that hold the solenoid assembly onto the GEO3.1 body (SEE FIGURE 25B).

Firstly remove the solenoid valve from the body, this will expose the solenoid manifold which sits partially inside the GEO3.1 body (SEE FIGURE 25C).

Carefully pull the solenoid manifold out from the GEO3.1 body, exposing the gas transfer holes which lead to the bolt assembly (SEE FIGURE 25D). The solenoid gasket may still be attached to the body, if this is the case, carefully peel the gasket off the body and place to one side.

With the solenoid assembly completely removed from the GEO3.1 body, the bottom of the GEO3.1 body should now resemble FIGURE 25E. Ensure that the air transfer holes in the bottom of the body are free from contamination from any dirt, debris, paint or moisture and clear away any excess grease if it appears to be blocking any of the transfer holes.



FIG 25A

FIG 25B



FIG 25C

FIG 25D



FIG 25E

FIG 25F

(CONTINUED)

Check the underside of the solenoid valve to ensure that it is free from damage or debris (SEE FIGURE 25F).

The solenoid manifold has two gaskets, the top gasket **A** and the bottom gasket **B** as illustrated in FIGURE 25G. Carefully remove both gaskets from the solenoid manifold. Inspect and clean the top and bottom gaskets and the solenoid manifold, replacing any damaged components.

Using a small size hex key or flat headed screw driver, gently push the poppet and cap out of the solenoid manifold (SEE FIGURE 25H). Inspect and clean the poppet, paying particular attention to the condition front face and o-rings (SEE FIGURE 25I). If either is damaged or worn, the poppet will need replacing.

Reinsert the poppet into the solenoid manifold in the orientation shown in FIGURE 25J. Then insert the cap, ensuring that it is firmly held in the solenoid manifold.

Replace the top and bottom gaskets into their respective grooves in the solenoid manifold as shown in FIGURES 25K AND 25L. Applying a small amount of Eclipse Grease to the surface of the solenoid manifold and gaskets.

¹If the Solenoid Manifold is damaged remember to remove the poppet and cap before disposing of the Solenoid Manifold.



WARNING

IF YOU ARE UNSURE ABOUT PERFORMING A MAINTENANCE PROCEDURE PLEASE CONTACT YOUR NEAREST SERVICE CENTRE.

FIG 25G



FIG 25H



FIG 25I



FIG 25J



FIG 25K



FIG 25L



(CONTINUED)

Lastly inspect and clean the large solenoid gasket, replacing if damaged (SEE FIGURE 25M).


Apply a small amount of grease to the outer most groove surrounding the solenoid manifold pocket in the GEO3.1 body. Then making sure the top solenoid manifold gasket lies flat in the solenoid manifold, insert the solenoid manifold back into the GEO3.1 body (SEE FIGURE 25N).

Next place the solenoid gasket over the solenoid manifold ensuring that the gasket is secure in its groove in the GEO3.1 body (SEE FIGURE 25O). Make sure that the bottom solenoid manifold gasket is flat in its groove in the solenoid manifold.

Place the solenoid valve over the solenoid manifold (SEE FIGURE 25P), making sure the location holes line up with the threads in the GEO3.1 body (SEE FIGURE 25Q).

Replace the retaining screws which hold the solenoid onto the GEO3.1 using a 5/64" hex key (SEE FIGURE 25R). DO NOT over tighten screws in the solenoid assembly.

Maintenance of the solenoid assembly is complete.



⚠ WARNING ⚠

IF YOU ARE UNSURE ABOUT PERFORMING A MAINTENANCE PROCEDURE PLEASE CONTACT YOUR NEAREST SERVICE CENTRE.

THE PUSH ON PURGE SYSTEM (POPS)

⚠ WARNING ⚠

DE-GAS YOUR MARKER, DISCHARGING ANY STORED GAS IN A SAFE DIRECTION, AND REMOVE THE BARREL, LOADER, AIR SYSTEM AND ANY PAINTBALLS TO MAKE THE MARKER EASIER AND SAFER TO WORK ON.

THERE IS NO NEED TO REMOVE THE POPS FROM THE GEO3.1 FRAME FOR GENERAL MAINTENANCE. IF THE POPS IS REMOVED, ENSURE THE O-RING IS CORRECTLY SEATED BEFORE POPS RE-ATTACHMENT.

Fully depress the latch button then slide the bonnet forward while continuing to depress latch button (SEE FIGURE 26A).

When the bonnet is in the forward position (SEE FIGURE 26B) remove the latch button and spring from the bonnet (SEE FIGURE 26C) then slide the bonnet off the POPS body (SEE FIGURE 26D). Be careful not to lose the spring.

Carefully slide the push rod out from either side of the POPS body, taking care not to lose the two o-rings on the push rod (SEE FIGURE 26E).

Clean off any dirt, debris or moisture from the bonnet, the POPS body and the latch button (SEE FIGURE 26F).

Remove the POPS insert assembly using a 5/32" hex key (SEE FIGURE 26G). Remove the POPS pin from the POPS Insert.

Clean and check the condition of the 007 NBR70 o-ring on the outside of the POPS insert, replacing as necessary (SEE FIGURE 26H).



FIG 26A



FIG 26B



FIG 26C



FIG 26D



FIG 26E



FIG 26F



FIG 26G



FIG 26H

(CONTINUED)

Clean and check the condition of the single internal 005 NBR90 o-ring in the front of the POPS insert, replace if necessary (SEE FIGURE 26I). Lubricate this o-ring liberally using Eclipse grease.

Lubricate the narrow end of the POPS pin with a smear of Eclipse grease and push the pin, narrow end first, into the POPS insert so that it sits in the POPS insert and pokes through to the front (SEE FIGURES 26J & 26K).

Screw the POPS insert back into the POPS body ensuring that the o-ring end goes in first (SEE FIGURE 26G).

Replace the push rod into its designated slot (SEE FIGURE 26L), then slide a 004 NBR70 o-rings on both ends of the push rod. Make sure the push rod is centred in the POPS body (SEE FIGURE 26M).

Slide the bonnet over the POPS body and align the hole on the bonnet with the front hole on the POPS body (SEE FIGURE 26N).

Ensure the spring is on the latch button then slide them both into the POPS body through the hole in the bonnet, spring end first, making sure the latch button pokes out the right side of the bonnet (SEE FIGURE 26O).

Push the button down as far as it will go, then (while still holding down the button) slide the bonnet back until the button engages with the POPS body and cannot slide into the forward position (SEE FIGURE 26P).

You have now successfully cleaned and maintained the Push On Purge System.



FIG 26I



FIG 26J



FIG 26K



FIG 26L



FIG 26M



FIG 26N



FIG 26O



FIG 26P

⚠ WARNING ⚠

IF YOU ARE UNSURE ABOUT PERFORMING A MAINTENANCE PROCEDURE PLEASE CONTACT YOUR NEAREST SERVICE CENTRE.

The Fault Finding guide covers common symptoms, causes and solutions that are likely to be encountered by the average user. If an issue with the GEO3.1 cannot be solved using the Fault Finding guide, contact your nearest Eclipse Service Centre for assistance.

SYMPTOM	POSSIBLE CAUSE	SOLUTION
Although a fresh battery has been fitted, the GEO3.1 will not switch on.	The battery has been fitted incorrectly.	Fit the battery correctly with the positive terminal nearest to the side of the frame.
	The battery has drained on the shelf.	Replace with another fresh battery.
	The battery terminals are not making proper contact with the battery.	Remove the battery, gently bend the terminals towards where the battery will sit and then replace the battery.
The battery does not seem to last very long.	The battery type is of a low quality.	Use an alkaline or metal hydride battery. Do not use a low quality or rechargeable battery.
The GEO3.1 does not fire.	The POPS is not engaged.	Engage the POPS fully.
	Solenoid flow restrictor (SFR) set too low.	Increase the flow through the SFR.
	The SFR assembly is blocked.	Strip and clean the SFR assembly.
	Battery quality or level of charge is very low.	Install new high quality battery.
	The battery is flat.	Install new high quality battery.
	Training Mode is enabled.	Disable training mode.
	Trigger and trigger detection method are set up incorrectly.	Set up the trigger correctly (refer to “Setting the trigger” section).
	Trigger detection system is blocked.	Remove any wires or debris from the trigger detection system.
	The solenoid assembly is not plugged into GEO3.1 PCB correctly.	Plug solenoid assembly plug into the solenoid port on the GEO3.1 PCB.
The break beam sensor system is enabled but there are no paintballs in the breach.	Fill the loader with paint/ turn on loader.	

SYMPTOM	POSSIBLE CAUSE	SOLUTION
The GEO3.1 does not fire.	The micro-switch is not being activated.	Adjust the micro-switch activation screw accordingly.
	The micro-switch is damaged.	Replace the circuit board.
	The PCB is damaged.	
	The solenoid valve is damaged.	Replace the solenoid valve.
	The solenoid valve wires are damaged.	
The GEO3.1 does not cycle fully.	The bolt assembly is dirty or incorrectly lubricated.	Clean, re-lubricate and replace the o-rings on the bolt as necessary.
	The Dwell parameter is set too low.	Increase the Dwell parameter.
	A sticky or faulty poppet in the solenoid manifold.	Check the poppet, clean and replace as necessary.
The GEO3.1 is inconsistent.	The Dwell parameter is set too low.	Increase the Dwell parameter.
	The SFR is set too low.	Increase the flow through the SFR.
	Using poor quality paintballs.	Use better quality paintballs.
	A poor paintball to barrel bore match.	Use a better paintball to barrel bore size match.
	The inline regulator is supercharging.	Strip and clean inline regulator.
	Dirty body filter.	Strip and clean the body filter.
	Poor / inconsistent air supply into POPS.	Use a good quality preset air system.
The GEO3.1 is ineffeicent.	The Dwell is excessively high.	Reduce the Dwell.
The GEO3.1 has low rate of fire.	The solenoid flow restrictor is set too low.	Increase the amount of flow on the SFR.
	The force setting on the loader is too low.	Adjust the loader force feed setting.

SYMPTOM	POSSIBLE CAUSE	SOLUTION
The GEO3.1 degasses very slowly.	The body filter is blocked / damaged.	Clean the body filter and inspect for damage. Replace if damaged.
The GEO3.1 leaks from the solenoid assembly.	Check that the three solenoid gaskets are intact and seated in their designated pockets both in and around the solenoid manifold.	Replace any of the solenoid gaskets if they are damaged.
	GEO3.1 solenoid assembly is over-pressurising.	Check the inline regulator output pressure and consequent velocity. Adjust accordingly. Strip and clean the SL4 inline regulator. Replacing the seals as necessary.
	Debris on / damage to poppet.	Clean / replace the poppet.
	Damaged GEO3.1 solenoid valve.	Replace the GEO3.1 solenoid valve.
GEO3.1 leaks down the barrel.	Front or rear prop shaft 14 x2 NBR 70 o-rings are damaged, dirty or dry.	Replace, clean and lubricate 14 x 2 NBR 70 o-rings on prop shaft.
	Internal 017 NBR 70 o-ring and external 020 NBR 70 o-rings on bolt can are damaged, dry or dirty.	Replace, clean and lubricate 017 NBR 70 o-ring and 020 NBR 70 o-rings on the bolt can.
Gas vents quickly down the barrel as soon as the GEO3.1 is gassed up.	The bolt is stuck in a forward position.	Push the bolt backwards.
	Main prop shaft 014x2 o-ring is damaged or an incorrect size.	Replace with a new 014x2 size o-ring.
The GEO3.1 is chopping or trapping paint.	The loader has too high a force feed setting.	Adjust the loader to a lower force feed setting.
	Poor quality paintballs.	Use better quality paintballs.
	The break beam sensor system is switched off.	Switch on the break beam sensor system.
	The bolt is dirty causing the incorrect detection of paintballs.	Clean the bolt and breach.

SYMPTOM	POSSIBLE CAUSE	SOLUTION
The GEO3.1 is chopping or trapping paint.	The break beam sensor system is dirty causing the incorrect detection of paintballs. solenoid.	Clean the break beam sensor system.
	Incorrectly seated rubber bolt tip.	Re-seat the rubber bolt tip.
	Damaged rubber bolt tip.	Replace the rubber bolt tip.
The GEO3.1 has low velocity on the first shot.	The FSDO parameters are set too low to overcome o-ring stiction.	Adjust FSD COMP and FSD DLY parameters.
The GEO3.1 has high velocity on the first shot.	The FSDO parameters are set too high.	Adjust FSD COMP and FSD DLY parameters.
	The inline regulator output pressure is creeping.	Strip, clean and maintain inline regulator.
GEO3.1 has velocity drop-off during rapid fire.	The battery is poor quality or has insufficient power.	Use an Alkaline or metal hydride battery. Do not use a low quality or rechargeable battery.
	The SFR is set too low.	Increase the flow through the SFR.
	Air system/regulator does not flow fast enough to keep up.	Try another air system/regulator and replace as necessary.
	Sticky/over lubricated o-rings in bolt assembly.	Clean, re-lubricate and replace o-rings on bolt assembly as necessary.
	Blocked body filter.	Clean/replace the body filter as necessary.
	Solenoid poppet is sticking from debris or too much grease.	Clean and lightly grease the solenoid poppet.
	Poorly maintained inline regulator.	Strip, lubricate and rebuild inline regulator.
Constant low velocity.	The SL4 inline regulator is set too low.	Increase the output pressure of the SL4 inline regulator.
GEO3.1 trigger is very "bouncy".	Incorrect filter settings.	Check that your trigger filter and debounce settings suit your trigger set-up.

SYMPTOM	POSSIBLE CAUSE	SOLUTION
The break beam sensor system does not appear to be reading correctly.	The break beam sensor system is dirty.	Clean the break beam sensor system.
The break beam sensor system is not reading at all.	The break beam sensors are the wrong way around.	Check that the red receiver is on the right-hand side of the breech.
	There is a broken wire or contact, or a short circuit on either of the break beam sensor cables.	Check the plug on the cables. Check for cuts or pinches in the sensor cables.
	Either break beam sensor is back to front.	Check that the sensors face each other when installed.
	The rubber detents are broken / missing.	Change the rubber finger detents.
Two or more balls are being fed into the breech.	Loader feed force is set too high.	Reduce the feed force on the loader.
The break beam sensor system turns itself off after firing.	The eye is dirty.	Clean the eyes.
	The eye is faulty.	Replace the eyes.
	The eye is out of place.	Re-install the eyes then check the alignment.
When the GEO3.1 powers up, the right hand side of the screen is not displayed and the marker will not fire.	The trigger is permanently depressed.	Adjust the trigger until the selected trigger detection method is activated when the trigger is released.

The Fault Finding guide covers common symptoms, causes and solutions that are likely to be encountered by the average user. If an issue with the GEO3.1 cannot be solved using the Fault Finding guide, contact your nearest Eclipse Service Centre for assistance.

ECLIPSE SERVICE CENTRES

Are you unsure of where to send your GEO3.1 to be repaired or serviced? If your local Eclipse dealer can't assist you, why not contact your nearest certified Eclipse Service Centre and arrange for them to undertake any work that you require.

A map listing all of our Service Centres and their contact details can be found in the SUPPORT section of the Planet Eclipse web site at

www.planeteclipse.com/site/service-centres

For any Technical Support or Customer Service enquiries please ensure that you have registered your product (where applicable) using the Warranty Card in this manual or online prior to contacting the appropriate representative in your region.

ECLIPSE SERVICE CENTRES

Map Navigation

Planet Eclipse
ECLIPSE SERVICE CENTRES

Map Navigation

Find your local Eclipse Service Centre by highlighting your chosen flag. You will be able to search for details of that country's location. Click and drag to zoom the map. Drag the map to see how to make a zoom button.

Sending in a Marker?

Before sending in your marker for scanning please follow these instructions to ensure effective & timely service.

1. Complete the form: [Click Here to Download](#)
2. Complete the form: Mark with your PIN code and date.
3. Complete the form: Mark with your PIN code and date.
4. Complete the form: Mark with your PIN code and date.
5. Complete the form: Mark with your PIN code and date.
6. Complete the form: Mark with your PIN code and date.
7. Complete the form: Mark with your PIN code and date.
8. Complete the form: Mark with your PIN code and date.
9. Complete the form: Mark with your PIN code and date.
10. Complete the form: Mark with your PIN code and date.

Region	Name	Country	Notes
USA	Atlanta	USA	See the Notes column
USA	Chicago	USA	See the Notes column
USA	Denver	USA	See the Notes column
USA	Los Angeles	USA	See the Notes column
USA	London	USA	See the Notes column
USA	Phoenix	USA	See the Notes column
USA	Portland	USA	See the Notes column
USA	San Francisco	USA	See the Notes column
USA	Seattle	USA	See the Notes column
USA	Wichita	USA	See the Notes column
USA	Winnipeg	USA	See the Notes column
USA	Yonkers	USA	See the Notes column

OPERATIONAL OVERVIEW

Below is a brief overview of what happens when you fire your GEO3.1. The location of parts discussed in the text below can be found on pages 68-69.

Assuming the GEO3.1 is gassed up and turned on [FIGURE 27A](#) shows the marker in its idle position. The firing chamber is full of compressed air, the prop shaft is pushed back into the back cap by this compressed air. The bolt is held back by the air in the bolt can. Both the firing chamber and the bolt can are supplied with air via the solenoid valve.

Providing a ball is in the breach when the trigger is pulled, a signal is sent to the solenoid valve which shuts off the supply of air to the firing chamber and allows the air in the bolt can to be exhausted. This removes the force holding the bolt in its rear position and the bolt is propelled forwards ([FIGURE 27B](#)).

As the bolt passes the front prop shaft o-ring the firing chamber seal is broken and the air in the firing chamber vents down the bolt, in turn propelling a ball ([FIGURE 27C](#)).

As air is vented from the firing chamber the force pushing the prop shaft back is overcome by the spring tension in the back cap. The spring pushes the prop shaft forward. The front 14x2 o-ring on the prop shaft enters the bolt and seals off the firing chamber ([FIGURE 27D](#)).

The length of time the bolt remains in this forward position is dependant on dwell. When the solenoid has completed its dwell time, air is routed back into the bolt can and pushes the bolt back towards its rear position. Simultaneously the firing chamber is re-filled through the solenoid valve to the operating pressure set by the user via the inline regulator, and the prop shaft is pushed into its rear position by the air pressure inside the valve chamber ([FIGURE 27E](#)).



FIG 27A



FIG 27B



FIG 27C



FIG 27D



FIG 27E

PARTS LIST



PARTS LIST

- 01 Clamping feed tube assembly
- 02 Body
- 03 Bolt System
- 04 Rubber detent
- 05 BBSS unit
- 06 Front frame screw
- 07 Rear frame screw
- 08 Solenoid assembly
- 09 SL4 inline regulator assembly
- 10 Gas pipe
- 11 Pipe nut
- 12 Gas pipe assembly o-ring
- 13 Trigger assembly
- 14 Frame
- 15 9V battery
- 16 Printed circuit board
- 17 Push button strip
- 18 Display window
- 19 PCB screw
- 20 Navigation console
- 21 POPS assembly
- 22 POPS seal
- 23 Foregrip crown
- 24 Foregrip sleeve
- 25 Rubber grip
- 26 Body plug
- 27 Body FRM o-ring
- 28 Body filter
- 29 Body filter Retaining Screw
- 30 Solenoid Flow Restrictor
- 31 Solenoid Flow Restrictor Seal

SHAFT 4 BARREL


The Eclipse GEO3.1 comes as standard with an Eclipse Shaft4 barrel.^{1,4}

The barrel screws into the body of the GEO3.1 using a right hand thread meaning that if you hold the GEO3.1 pointing away from you the barrel screws into the body in a counter-clockwise direction.²

The barrel comprises of two parts, a barrel back (A) and a barrel front (B). The two parts are joined together with a left hand thread meaning that if you hold the barrel, with the back nearest you, the front unscrews in a counter-clockwise direction. The bore size of the barrel back is engraved at the end of the barrel back (C).³

On the barrel back there is a 016 NBR 70 o-ring (D) which prevents the barrel from vibrating loose from the GEO3.1 body when the marker is fired. There is also a 016 NBR 70 o-ring on the tip of the barrel back (E) helps with alignment when the two sections are screwed together.

Replace and lubricate these o-rings with Eclipse Grease as necessary.



¹The bore size of your Shaft4 may vary according to the model of GEO3.1 you have.

²The GEO3.1 will only accept COCKER threaded barrels. Do not use any other type of barrel thread.

³The Eclipse Shaft4 front and back barrel sections are not interchangeable with older version shaft front and back barrel sections (including Shaft3 barrel kits).

⁴The model of barrel accompanying your GEO3.1 may differ from described.


SL4 INLINE REGULATOR^{1,2}

¹The SL4 inline regulator should be reset to factory after re-assembly.


²Only use the SL4 inline regulator with the GEO3.1.

³Only use the SL4 GEO spring with the GEO3.1 SL4 inline regulator.

⁴If the Purge Poppet assembly is removed for maintenance ensure it is re-installed correctly, failure to do so may seriously damage the GEO3.1 solenoid valve.




GEO3.1 BOLT SYSTEM




¹The prop shaft assembly does not need to be fully disassembled for basic maintenance. Only if a leak around the prop shaft screw develops should disassembly take place.

GEO3.1 SOLENOID ASSEMBLY



¹The GEO3.1 solenoid valve is NON-SERVICEABLE. Any attempt to strip, dismantle or service the solenoid valve will immediately void your Warranty. For more information on the GEO3.1 solenoid valve please see page 56.

GEO3.1 PUSH ON PURGE SYSTEM (POPS)




TRIGGER ASSEMBLY





CLAMPING FEED TUBE ASSEMBLY

GEO3.1 CIRCUIT BOARD



SCREW	QTY	DESCRIPTION
	6	PCB SCREW (3), BEARING CARRIER SCREW (2), NAVIGATION CONSOLE (1) (M2.5 x 5 CAP HEAD SOCKET)
	2	SOLENOID SCREW (2) (M2.5 x 12 CAP HEAD SOCKET)
	4	RUBBER GRIP SCREW (4), BBSS COVERS SCREW (2) (6-32UNC x 5/16" COUNTERSUNK SOCKET)
	1	SHORT FEED NECK SCREW (10-32UNF x 1/2" CAP HEAD SOCKET)
	2	POPS SCREW (10-32UNF x 1" CAP HEAD SOCKET)
	1	Micro-switch SCREW (6-32 UNC x 1/2" SOCKET SET SCREW)
	2	TRIGGER ADJUSTMENT SCREW (6-32 UNC x 3/16" SOCKET SET SCREW)
	3	TRIGGER PIN RETAINING SCREW (6-32 UNC x 1/8" SOCKET SET SCREW)
	3	FRAME SCREW (2), BODY FILTER (1) (10-32 UNF x 3/8 SOCKET BUTTON HEAD)

 <p>20X2</p>	Back Cap	 <p>016</p>	Shaft4 Barrel Back (x2)
 <p>18x2</p>	POPS Seal	 <p>015</p>	SL4 Swivel Bolt Bumper (Middle) NBR90
 <p>14x2</p>	SL4 Inline Regulator Piston Propshaft (x2) Bolt Rear	 <p>011</p>	SL4 Inline Regulator Adjuster Outside
 <p>020</p>	Bolt Can External (x2)	 <p>009</p>	Propshaft Retaining Screw Rear
 <p>017</p>	Front Regulator Mount (Body) Bolt Can Internal	 <p>008</p>	SL4 Inline Regulator Adjuster Inside
		 <p>007</p>	Gas Transfer Pipe POPS Insert External
		 <p>006</p>	Body Plug Feed Tube Swivel
		 <p>005</p>	POPS Insert Internal (NBR 90)
		 <p>004</p>	POPS Push Rod
		 <p>7x1</p>	Propshaft Tip
		 <p>5x1</p>	Solenoid Flow Restrictor (x2)
		<p>4x1</p>	Propshaft Retaining Screw Front

All O-rings are NBR70 durometer unless otherwise stated.

THE MENU TREE

The  symbol indicates parameters that are locked when the Tournament Lock is on. See Accessing the Menu System on page 27 for instruction on releasing the Tournament Lock.

Parameters followed by a * are part of the Smart Menu System and will only be displayed depending on your chosen settings. (e.g. The BS ON ROF parameter will only become available if the ROF CAP parameter is set to on).

MAIN MENU

TURN OFF	Turn off the GEO3.1.
PRESET	
 LOAD	USER 1 Load the USER 1 settings. USER 2 Load the USER 2 settings. FACTORY(Default) Load the default factory settings (semi-automatic). NPPL Load NPPL compliant settings. PSP 10 Load the PSP 10 balls per second (BPS) compliant settings. PSP 12 Load the PSP 12 balls per second (BPS) compliant settings. MS 10 Load Millennium Series 2010 compliant settings. CANCEL Cancel the load operation.
 SAVE	USER 1 Save the current settings as the USER 1 settings. USER 2 Save the current settings as the USER 2 settings. CANCEL Cancel the save operation.
BACK	Return to Main Menu.
 FIRE MODE	SEMI (Default) Select semi-automatic mode of fire. RAMP Select ramping mode of fire. CANCEL Cancel the mode selection.
 ROF CAP	ON Rate of fire cap on. OFF (Default) Rate of fire cap off. CANCEL Cancel selection.
 BS ON ROF*	4.0 - 30.0 bps Maximum rate of fire with breach sensor on (ROF CAP dependant). (Default 15.0bps)
 BS OFF ROF	4.0 - 15.0 bps Maximum rate of fire with breach sensor off. (Default 10.0bps)

RAMP SETUP* (FIRE MODE DEPENDANT)

TYPE	STEP (Default) LINEAR CANCEL	Step ramping. Linear ramping. Cancel selection.
RATE*	0 - 100%	Percentage linear ramp rate (TYPE dependant). (Default 50%)
SEMI SHOTS	3 - 9	Number of shots before ramping can start. (Default 3)
KICK IN	3.3 - 10.0 pps	Rate at which the trigger has to be pulled in pulls per second (pps) before ramping can start. (Default 5pps)
SUSTAIN	3.3 - 10.0 pps	Rate at which the trigger has to be pulled in pulls per second (pps) in order to maintain ramping. (Default 5pps)
RESTART	0.0 - 1.0 s	Time in seconds (s) after the last trigger pull during which ramp can be restarted. (Default 0.0s)
BACK		Return to Main Menu.

TIMING

DWELL	10.0 - 30.0 ms	Solenoid energise time in milliseconds (ms) for each shot. (Default 26.2ms)
FSD COMP	0.0 - 5.0 ms	First shot drop-off compensation time in milliseconds (ms). (Default 5.0ms)
FSD DELAY	00:00 - 04:00	First shot drop-off delay. (Default 00:30)
BACK		Return to Main Menu.

FILTER

DEBOUNCE	Level 9 Level 8 - 2 Level 1 Cancel	Use trigger Debounce level 9 (highest level of trigger bounce filtering). Use trigger Debounce level 8 - 2. (Default LEVEL 5) Use trigger Debounce level 1 (lowest level of trigger bounce filtering). Cancel Debounce selection.
EMPTY	1.0 - 20.0 ms	Time in milliseconds (ms) that the breech must remain empty before the BBSS looks for a paintball. (Default 4.0ms)
FULL	1.0 - 20.0 ms	Time in milliseconds (ms) that a paintball must be in the breech for the GEO3.1 to be ready to fire. (Default 4.0ms)
PULL TM	3.0 - 25.0 ms	Time in milliseconds (ms) that the trigger must be pulled for a shot to be fired. (Default 6.0ms)
RELEASE TM	3.0 - 25.0 ms	Time in milliseconds (ms) that the trigger must be released before a pull can be recorded. (Default 6.0ms)
PULL PT*	51 - 99%	Percentage at which the trigger OPTO sensor pull point is set (TRIGGER dependant). (Default 85%)
RELEASE PT*	1 - 49%	Percentage at which the trigger OPTO sensor release point is set (TRIGGER dependant). (Default 15%)
BACK		Return to Main Menu.

(CONTINUED)

HARDWARE

TRIGGER

OPTO (Default)	Use OPTO sensor to detect trigger operation.
SWITCH	Use micro-switch to detect trigger operation.
CANCEL	Cancel trigger detection method selection.

SOLENOID

LO PWR (Default)	Select standard solenoid power level.
HI PWR	Select high power level for solenoid.
CANCEL	Cancel solenoid power level selection.

SOUND

Off	Turn off audible indicator.
On (Default)	Turn on audible indicator.
Cancel	Cancel audible indicator selection.

TONES*

Off	Turn off audible tone when any button is pressed (SOUND dependant).
On (Default)	Turn on audible tone when any button is pressed (SOUND dependant).
Cancel	Cancel audible tone selection.

BACKLIGHT

00:00 - 00:20	Time in seconds that the backlight comes on for (00:00 = no backlight). (Default 00:06)
---------------	---

RED LEVEL*

0 - 100%	Percentage of red light in backlight (BACKLIGHT dependant).
----------	---

GRN LEVEL*

0 - 100%	Percentage of green light in backlight (BACKLIGHT dependant).
----------	---

BLU LEVEL*

0 - 100%	Percentage of blue light in backlight (BACKLIGHT dependant).
----------	--

CONTRAST

0 - 30	LCD contrast level. (Default 14)
--------	----------------------------------

AUX OUT

Off	AUX socket output off.
On (Default)	AUX socket output on.
Cancel	Cancel AUX socket selection.

AUTO OFF

05:00 - 60:00	Time in minutes after which the GEO3.1 automatically powers off. (Default 20:00)
---------------	--

DBL CLICK


NONE	Double click is disabled entirely.
POWER UP	Double click for power up only.
ALL (Default)	Double click is fully enabled.
CANCEL	Cancel the double click selection.

BACK

Return to Main Menu.

TRAINING

Off (Default)	Training mode disabled.
On	Training mode enabled.
Cancel	Cancel training mode selection.



From time to time the software of the GEO3.1 may be updated, resulting in changes to the default values for some parameters. For the most up to date default values please consult the online version of this manual at www.planeteclipse.com

The arrangement of menus and sub menus displayed in the above menu tree may not be replicated in your marker due to any software updates that may have taken place since printing.

ECLIPSE E-PORTAL

⚠ WARNING ⚠

DE-GAS YOUR MARKER, DISCHARGING ANY STORED GAS IN A SAFE DIRECTION, AND REMOVE THE BARREL, LOADER, AIR SYSTEM AND ANY PAINTBALLS TO MAKE THE MARKER EASIER AND SAFER TO WORK ON.

The GEO3.1 is compatible with Eclipse E-Portal Software. This software is an upgrade to the GEO3.1 platform. The Eclipse E-Portal Software, USB cable and USB daughter board are sold as a kit, separate from the GEO3.1.¹

E-Portal allows you to connect the Eclipse GEO3.1 to a PC, where a number of operations can be performed:²

Update the marker firmware - from time to time new firmware may be released by Planet Eclipse. You can now install the latest firmware using the Eclipse E-Portal.



Alter the electronic parameters - the Eclipse E-Portal will give you full access to all of the parameters on the GEO3.1 circuit board.

Customise screen graphics - customise the boot up screen graphic.

¹If you already own an Eclipse E-portal kit (such as the kit included with the Eclipse SLS or CSL Ego), this kit will be compatible with the GEO3.1.

²Minimum system requirements :

Monitor Resolution - 1024x768 or higher, CD-ROM drive, Keyboard, Mouse, USB socket, 5MB of hard disk space, 1GHz Processor, 384Mb RAM, Microsoft® Windows® XP / Windows Vista / Windows 7 / Windows 8, internet connection (required for software and firmware updates).



INDEX

- Actual Rate of Fire.....22, 26
Advanced Trigger Filter Setup.....36
Air System.....6, 16, 17, 18, 20
ALARM.....25, 41, 82
AUTO OFF.....39, 81
AUX OUT.....22, 23, 39, 81
BACKLIGHT.....10, 38, 81
Basic Trigger Filter Set-up.....36, 64
Battery.....7, 21, 22, 37,61, 64, 69, 76
Battery Level Indicator.....22, 25
BBSS Socket.....76
Bearing Carrier Assembly.....51, 54, 55, 75
Bearing Carrier Screw.....75, 77
BLU LEVEL.....38, 83
Blanking Plug.....19,53
Body Filter.....47, 62, 63, 69, 77
Body Plug.....45, 69, 78
Bolt.....48-49, 62-64, 67, 69, 72
Bolt Bumper O-ring.....72, 78
Bolt Front O-ring.....72, 78
Bolt Rear O-ring.....72, 78
Bolt System.....48-50, 69, 72
Bolt Tip.....49, 64, 72
Bolt Can.....48-49, 63, 67, 72
Bolt Can External O-rings.....72, 78
Bolt Can Internal O-ring.....72, 78
Break Beam Sensor System (BBSS).....9, 10, 23, 42-43, 61-65, 69, 76
Break Beam Sensor System Indicator.....23
BS OFF ROF.....23, 30, 79
BS ON ROF.....23, 30, 79
CANCEL.....27
Clamping Feed Sprocket Screw.....14, 20, 75
Clamping Feed Swivel.....75
Clamping Feed Tube.....20, 75
Clamping Feed Tube Screw.....75, 77
Clamping Lever.....14, 75
Clamping Feed Tube Insert.....75
Circuit Board (PCB).....69, 76
Contrast.....39, 81
DBL CLICK.....39, 81
DEBOUNCE.....34, 36, 66, 80
DWELL.....33, 62, 80
E-Portal.....83
EMPTY.....34, 80
EXIT.....82
Eye Cover.....42, 43
Eye Cover Screw.....42, 43, 77
FACTORY.....6, 29, 79
FILTER.....34, 80
FIRE MODE.....30, 79
Foregrip Crown.....44-45, 51-52, 69
Foregrip Sleeve.....18, 44, 69
Frame.....51-52, 69
Frame Screw.....51-52, 69, 77
Front Stop Trigger Screw.....12-13, 36, 75, 77
FSD COMP.....33, 64, 80
FSD DELAY.....33, 80
FULL.....34, 80
GAME.....41, 82
Game Timer.....22, 25, 41, 82
Gas Pipe.....15, 69, 78
GAUGE.....25, 40, 82
GAUGE MAX.....40, 82
GRN LEVEL.....38, 81
HARDWARE.....36, 81
Inline Regulator Adjuster Screw.....18, 71, 78
Inline Regulator Assembly.....69, 71
Inline Regulator Body.....71
Inline Regulator Bottom.....71
Inline Regulator Piston.....71, 78
Inline Regulator Spring.....71
Inline Regulator Swivel.....15, 71, 78
KICK IN.....32, 80
Latch Button.....74
LINEAR.....31, 80
LOAD.....29, 79
Lock Indicator.....22, 25, 27, 79
Magnet Return Strength Screw.....13, 77, 79
Main Menu.....27, 28, 79
Menu System.....26, 28, 79-82

Menu Tree.....79-82
Micro-switch Activation Screw.....13, 76, 77
MS 10.....29, 79
Navigation Console.....10, 22, 69
NPPL.....29, 79
Parameters.....10, 26, 27, 28
PCB Retaining Screw.....77
Peak Rate of Fire.....22, 26
Pipe Nut.....15, 71, 78
Plastic Push Button Strip.....69
Poppet.....14
Poppet Cap.....14
POPS Body.....74
POP Bonnet.....74
POPS Insert.....74
POPS Pin.....74
POP Retaining Screws.....74, 77
PRESET.....29, 79
Prop Shaft.....48-50, 67, 72
Prop Shaft Back Cap.....48-50, 72
Prop Shaft Back Cap O-ring.....48-50, 72, 78
Prop Shaft Bumper.....48-50, 72
Prop Shaft Middle O-ring.....48-50, 72, 78
Prop Shaft Retaining Screw.....48-50, 72
Prop Shaft Spring.....48-50, 72
Prop Shaft Tip.....48-50, 72
PSP 10.....29, 79
PSP 12.....29, 79
PULL PT.....35, 80
PULL TM.....35, 80
Purge Poppet Assembly.....73
Push Operated Purge System (POPS).....69,74
RAMP.....30, 79
RAMP SET UP.....31, 80
RATE.....31, 80
Rear Stop Trigger Screw.....12, 75, 77
RED LEVEL.....38, 81
Regulator Seal.....71
RELEASE PT.....35, 80
RELEASE TM.....35, 80
RESTART.....32, 80
ROF CAP.....30, 79

Rubber Detent.....43, 69
Rubber Grip Screw.....77
Run Screen Layout.....22
SL4 Inline Regulator.....69
SAVE.....29, 79
SEMI.....30, 79
SEMI SHOTS.....32, 80
Shaft4 Barrel.....11, 70
SHOT COUNT.....22, 25, 40, 82
SOLENOID.....37, 81
Solenoid Assembly.....56-58, 61, 63, 73
Solenoid Flow Restrictor (SFR).....6, 19, 53, 61-64, 69, 78
Solenoid Manifold.....56-58, 62-63, 73
Solenoid Manifold Bottom Gasket.....56-58, 73
Solenoid Mainfold Top Gasket.....56-58, 73
Solenoid Retaining Screw.....56-58, 73, 77
Solenoid Valve..... 56-58, 61, 63, 73
Solenoid Valve Gasket.....56-58, 73
SOUND.....37, 81
Sound Indicator.....22, 24
Spring Return Strength Screw.....13, 75, 77
START.....41, 82
STEP.....31, 80
SUSTAIN.....32, 80
TIMING.....33, 80
TONES.....37, 81
TRAINING.....23, 40, 81
Trigger.....8, 12, 13, 54, 55, 75
TRIGGER.....81
Trigger Assembly.....69, 75
Trigger Detection Indicator (TDI).....13, 24
Trigger Pin.....12, 75
Trigger Pin Locking Set Screw.....12, 75
Trigger Leaf Spring.....12, 75
TURN OFF.....8, 10, 28, 79
TYPE.....31, 80
USB Cable.....83
USER1.....29, 79
USER2.....29, 79
User Interface.....22
Velocity.....18



ECLIPSE PAINTBALL

This product is covered by and / or Licensed under one or more of the following patents;

G.B. Patents: 2,342,710; 2,345,953; 2,352,022; 2,391,292; 2,391,063;
U.S. Patents: 7,836,873; 7,603,995; 7,073,284; 8,104,463; 7,509,953; 7,921,839; 7,089,697; 7,866,307;
 8,082,912; 7,076,906; 7,607,424; 7,980,238; 6,311,682; 6,748,938; 6,860,259; 6,941,693; 6,973,748;
 5,881,707; 5,967,133; 6,035,843; 6,474,326; 6,637,421; 6,644,295; 6,810,871; 6,901,923; 7,121,272;
 7,100,593; 7,610,908; 7,603,997; 7,946,285; 6,349,711; 7,044,119; 7,185,646; 7,461,646; 7,556,032;
 7,591,262; 7,617,819; 7,617,820; 7,624,723; 7,640,925; 7,640,926; 7,866,308;

Application Numbers.

12/256,832; 12/613,958; 12/493,777; 11/654,721; 11/747,107; 12/503,504; 11/781,821; 60/832,548;
 11/965,886; 10/280,115; 12/511619; 13/182135; 13/334575; 13/165234

Additional U.S. and International Patents may be pending.

© 2013 Copyright Planet Eclipse Ltd. Eclipse, Planet Eclipse, the Estar Logo Device, Ego, Geo, Etek, Etha and EMC are all either design trademarks, registered trademarks or trademarks of Planet Eclipse Ltd. All other trademarks are property of their respective owners.

USA

130 Franklin Street
 Building L4 & L5
 Warren, RI. 02885, USA
 Call: +1 401 247 9061
 info.usa@planetecclipse.com

UK

Unit 14 Premier Park, Acheson Way
 Trafford Park Road, Trafford Park
 Manchester, M17 1GA, England
 Call: +44(0) 161 872 5572
 info.europe@planetecclipse.com

GET MORE AT
 PLANETECLIPSE.COM

