

Blackmaxx, Tracer, Rampage Retrofit Guide

FIGURE 1

All of the markers in figure 1 do not have the external retrofit device installed. However you must check to see if they have the new factory installed safety release device as shown in figure #3 & 4 before playing with this marker! If your marker does not have the factory installed safety release device or the external retrofit device you must call or e-mail PMI to arrange for your free retrofit service. Call PMI toll free at 800-579-1633 or e-mail at info@pminetwork.com for further details regarding returning your marker for this free upgrade. Do not use the marker prior to calling PMI.



FIGURE 2

All of the markers in figure 2 have the external retrofit device installed as shown circled in blue below. These markers are ready to use.



FIGURE 3

The markers shown in figures 3 & 4 have the new factory installed safety release device. These markers are ready to use.



FIGURE 4

