

JT ProFlex Faceplate Installation –

Step 1 – Line new clear faceplate bottom with goggles and place “Christmas Tree” style prongs in appropriate holes in nose piece.



Step 2 – Push faceplate and goggles together. “Christmas Tree” prongs should slide into holes in goggle. For best results, reach inside the nose area of the goggles and push towards the faceplate while pushing the “Christmas Trees” through the holes. You should be able to see the tips of the “Christmas Tree” prongs through your lens.



Step 3 – Gather hardware from when you removed the old yellow faceplate from your goggles and using a phillips head screwdriver, secure earpieces in place. Repeat this for the left side.



Step 4 – When the JT ProFlex is complete you should have the nose of your faceplate over the top of the goggle frame.



Contact us:

JT Paintball
11723 Lime Kiln Rd.
Neosho Missouri,
800-220-3222