

The marker is chopping or trapping paint



POSSIBLE CAUSE: Feeding force from loader is too low.

SOLUTION: Adjust loader setting / use higher feeding force loader.




POSSIBLE CAUSE: Barrel is dirty.

SOLUTION: Clean the barrel.



POSSIBLE CAUSE: Breech is dirty.

SOLUTION: Clean the breech.



POSSIBLE CAUSE: Eye sensor is dirty.

SOLUTION: Clean eye sensor.



POSSIBLE CAUSE: Wrong match between paintball and barrel.

SOLUTION: Use right size and quality paintball.