




Blitz will not switch on




POSSIBLE CAUSE: Battery is dead.

SOLUTION: Use fresh new battery.



POSSIBLE CAUSE: The battery terminals did not connect to battery harness.

SOLUTION: Reconnect battery to battery harness.



POSSIBLE CAUSE: Battery harness is damaged.

SOLUTION: Replace the battery harness.



POSSIBLE CAUSE: Damaged Zen board.

SOLUTION: Replace Zen board.