

THIS DIAGRAM ILLUSTRATES THE O-RINGS RESPONSIBLE FOR AIR LEAKING FROM INSIDE THE FACE OF THE BOLT.

SHOCKER XLS DOWN BARREL LEAK GUIDE