

Leaking from the Feedneck



POSSIBLE CAUSE: Valve installed incorrectly

SOLUTION: Bigger opening hole is facing the barrel side



POSSIBLE CAUSE: Front Valve O-Ring (R012) is damaged

SOLUTION: Replace Front Valve O-Ring



POSSIBLE CAUSE: Cup Seal Guide is jammed in the valve

SOLUTION: Replace cup seal guide and make sure it goes through the valve completely.