


Blitz does not fire



POSSIBLE CAUSE: Low Battery.

SOLUTION: Use fresh new battery.



Back out the trigger leave some space between the trigger and micro switch.



Too far back and too close to the micro switch at the back of the trigger.

POSSIBLE CAUSE: Trigger set up incorrectly.

SOLUTION: Set trigger up correctly.



POSSIBLE CAUSE: Eye sensor is on without paintball in the breech.

SOLUTION: Fill paintball in the loader or turn off the Eye.