



- The global ROF cap must be set to 13 to cap the marker at 13.33 bps to comply with PSP rules.
- 3. **NXL** – The first three shots are semi auto. On the 4<sup>th</sup> shot, the user may hold in the trigger and the gun will shoot in full auto until the trigger is released. After a one second delay of trigger inactivity, the 3 shots semi-auto sequence will restart.
  - The global ROF cap must be set to 13 to cap the marker at 13.33 bps to comply with NXL rules.
- 4. **Millennium** – Ramping mode specifically designed for Europe's Millennium Series.
- 5. **Ramping** – Uses a linear ramping algorithm to increase your rate of fire. You can choose when you want your marker to start ramping and how fast your marker will ramp.
  - The ramp deactivation is always 2 bps lower than the ramp activation.
  - Each "programming click" corresponds to a 10% increase in ramping speed. Eg: 1 click = 10%, 10 clicks = 100%, 20 clicks = 200%
  - The ramping percentage and ramp activation settings in the programming menu are GLOBAL settings. Any other firing mode which has a ramping subroutine will use the ramp activation and percentages as dictated by the programming menu.
- 6. **PSP Style Ramping** – The first three pulls are semi auto. On the 4<sup>th</sup> shot, the marker will fire in ramping mode. After a one second delay of trigger inactivity, the three shot semi-auto will restart.
- 7. **PSP Style Auto Response** – The first three pulls are semi auto. On the 4<sup>th</sup> shot, the marker will fire in Auto Response mode. After a one second delay of trigger inactivity, the three shot semi-auto will restart.
- 8. **Semi/Ramping Transition** – The first three shots are semi auto; the marker then converts to ramping mode.
- 9. **Ramping/Semi Transition** – For the first 300 pulls, the marker will be in ramping mode; after the 300<sup>th</sup> pull, the marker will convert to semi auto.
- 10. **Musket Ball Mode** – This is essentially a dwell ramp mode. The user must hold in the trigger to "charge" their marker. The gun actually fires on the trigger release. When the trigger is first pulled and held down, the software will start at the user set dwell (8 ms default) minus 10 ms. Over the course of five seconds, the software will add 2 ms of dwell up to the user set dwell for every second the trigger is continually depressed. After 5 seconds, the marker will be fully charged.
  - If the user just pulls the trigger and immediately releases, the paintball probably won't make it out of the barrel; if the user holds the trigger for 3 seconds, the velocity of the paintball will be extremely low, etc.

### Wireless Operation:

The hardware on the HATRED board was developed with two prime concerns: overall speed and wireless expandability. Your HATRED board comes equipped with a high-performance wireless transceiver which is fully capable of an almost unlimited array of wireless applications. The board you just purchased is wholly capable of computer and PDA synchronization, wireless "intellifeeds," and statistical transmission and analyses.

The HATRED board comes pre-loaded with SYMBIO SYNC loader board software. To synchronize your HATRED board with your SYMBIO loader board:

- 1.) Make sure your SYMBIO is fully powered off. Press and continue to hold the SYMBIO loader board's button in until the LED flashes white. Release the button; the LED should now be solid white.
- 2.) Enter the programming menu on your HATRED gun board and scroll to the WIRELESS ADDRESS SELECT (white LED).
- 3.) Set your HATRED gun board to the desired wireless address. Your SYMBIO will pulse to signify acceptance of the change and then enter normal wireless mode.

Each and every HATRED gun board broadcasts that gun's current rate of fire with every wireless transmission. Simply, the faster you shoot, the faster the SYMBIO loader board will load paintballs – an industry

first. The ROF transmissions allow your loader to infer EXACTLY how fast your marker is shooting and load paintballs accordingly. Your SYMBIO will never starve your marker and simultaneously will never overfeed and smash brittle paint.

The REVISION 2 HATRED gun board will send a wireless LOAD command on every shot fired –and- on every trigger pull. If your eyes are on with no paint in the breach and you pull the trigger, the HATRED will assume you are trying to fill up the feedstack and will send a wireless LOAD command in an attempt to do so. This feature enables you run your loader dry and then refill without starving your marker.

### Eye Operation:

The HATRED board is 100% compatible with both 2C™ and 4C™ eye systems. The software of the HATRED board will automatically detect whether a two eye or four eye system is installed on your marker.

When using the 4C eye system at high rates of fire, the HATRED board will initiate the firing cycle based off the top set of eyes. This allows the marker to shoot at much higher rates of fire.

### Definitions:

**Debounce** – The HATRED's debounce algorithm assists in eliminating unwanted shots caused by "trigger noise," while simultaneously ensuring that every pull is read. If the marker has intermittent or continuous "full auto" like fire, increase the debounce setting.

**Dwell** – Dwell is the amount of time that the solenoid is "charged." A dwell that is too low may result in a gun that doesn't fire, is inconsistent and/or has drop off. If the dwell is set too high, the overall rate of fire will decrease and the marker may become less air efficient. The factory default of 8ms should be considered a starting point for setting your dwell. Increase your dwell in 1 ms increments until your velocity is no longer affected. For Marq's and Protégé's, your dwell should remain in the 6ms-13ms window.

**Eye Delay** – The eye delay is the amount of time the gun will pause after sending a ball before it will fire. The stock eye delay of 4 ms is a conservative setting. On most guns, the Eye Delay can be lowered until the user experiences chopping. When using an agitated loader, the eye delay should be set to 5 ms or higher. The higher the eye delay, the slower the marker and less chance of paint breakage.

**ABS** – The Anti-Bolt Stick feature increases the dwell of the marker's first shot after a period of inactivity. The ABS feature assists in eliminating first shot drop-off. The higher the ABS, the "harder" the marker's first shot.

**AMB** – Anti-Mechanical Bounce feature assists the user in eliminating mechanical bounce. Mechanical bounce is caused by the marker recoiling.

**EXTREMELY IMPORTANT.** The AMB software in the HATRED Software Release 3 is different from any other AMB algorithm on the market. The AMB value which the user sets is actually the KICK IN TIME for the placement of an AMB window in the firing cycle. While the user sets the initiation value, the software automatically calculates the correct duration of the window itself. The faster the gun's firing cycle (as in the faster the bolt travels forward and retracts), the lower the AMB time. **15 ms is an ideal time for Protégé's whereas 25 ms is an ideal value for Marq's.** If your gun has bounce issues, please increase and decrease your AMB values by 2 ms increments until your AMB window is positioned correctly in your firing cycle and your bounce issues are eliminated. A higher AMB value does not mean the gun will bounce less!

**Note:** Setting your AMB value to 1 will disable AMB altogether.

**Max ROF** – This feature allows the user to cap the maximum rate of fire of their marker. Some leagues, such as the PSP, require that guns not exceed 15.4 bps. The Max ROF feature is adjustable from 10-35 bps in 1 bps increments.

**Note:** Dip switch 1 must be ON for your ROF cap to be enabled.

**IMPORTANT:** We highly recommend leaving your Max ROF at 20 cps or below. Anything higher than this CAN blow your solenoid. Hater Paintball simply cannot be responsible for damaged solenoids.

**Forced Shot** – If the eyes are enabled, but the breach is empty, the user may force a shot by holding in the trigger for approximately one second. This feature is useful in the event that a ball has been pushed into the detents and is unreadable by the eyes. A forced shot will clear the breach and load the next paintball as normal.

**Ramp Activation** – This feature sets your ramp activation for all ramping modes. Your ramping will not kick in until this activation point has been reached. A lower ramp activation "kicks in" easier than a high activation. **Note:** The ramp deactivation is always two bps less than the ramp activation. **Ramp Percentage:** This applies to all ramping modes and tells your gun how fast to ramp. The higher the setting, the faster your marker will shoot. **Factory Default Reset:** To reset all settings back to their factory defaults, go into the programming menu and select the flickering blue LED. Click the trigger once to reset everything back to its factory default value.

### War r anty:

The HATRED gun board is warranted free from any and all manufacturing defects or software bugs for a period of one year from the purchase date of the product.

Problems caused by customer negligence are not covered under warranty. "Negligence" includes, but may not be limited to, using batteries other than a single Alkaline 9V, breaking components off the board, and other improper usage.

### Developed By

**HATER PAINTBALL LLC**  
 2752 Michigan Avenue  
 Unit Four  
 Kissimmee, Florida 34744  
 United States  
 317-354-5201 (p)  
 317-203-0719 (f)  
 info@haterpaintball.com  
 www.haterpaintball.com

### Tech Support Offered Through

**Paintball Solutions**  
 Paintball Solutions  
 55 Howard Avenue  
 Des Plaines, IL 60018  
 800.220.3222  
 tech@paintballsolutions.com

*4C, the four eye system, and all associated intellectual property are property of Extreme Paintball Designs.*